

Serie **Individual**



Individual 520.360 GH

Operating instructions

**Before transporting and using the machine,
please read the instructions thoroughly!**

Seriové číslo / Serien Nummer / Serial Number _____

Service and information

Your BOMAR dealer:

Direct BOMAR contact:

BOMAR spol. s r.o.
Těžební 1236/1
62700 Brno
Czech Republic, EU

telefon: +420 – 533 426 100
fax: +420 – 533 426 109
e-mail: info@bomar.cz
www: <http://www.bomar.cz>

We are available:

Mondays to Fridays

7⁰⁰ – 16⁰⁰

Version:

1.22 / Feb. 2013
rev. 2

BOMAR, spol. s r.o. © – Subject to modifications and amendments.

EC Declaration of Conformity

1) We

BOMAR, spol. s r.o.
Těžební 1236/1
627 00 Brno, The Czech Republic
Id.no: 48908827

declare herewith,

that the following designated device based on its conception and construction as well as the design launched by us meets the relevant basic safety requirements of the decrees of the government. In the event of any device modification not approved by us this declaration shall lose its validity.

Name: **Band Saw**
Type range: **Individual 520.360 (D)GH**
Serial number:

Manufacturer: **BOMAR, spol. s r.o., Těžební 1236/1, 627 00 Brno**

Product data

Determination: for cross dividing and cutting of rolled and towed bars and profiles made of steel, stainless steel, non-ferrous metals and plastics.

Description: stand, table, cutting unit with the saw band and drive, clamping device , Hydraulic, cooling system, el. switch board with control panel.

Technical data: cutting rate 20–120 m.min⁻¹, +60° to -60° for DGH, 0° to 60° for GH
Total dimensions in mm (l×w×h) 2350×2450×2100,
Supply voltage 400 V TN-C-S, 400 V TN-C or 230 V TN-C
Total power requirement 5,2 kW, weight 1400 kg

The applied decrees of governments: **No. 17/2003 Coll.** (Directive 73/23/EEC)
No. 616/2006 Coll. (Directive 2004/108/EC)
No. 17/2003 Coll. (Directive 2006/95/EC)

The applied harmonized standards,

National standards and technical specifications: ČSN EN ISO 12 100-2:2004, ČSN EN 13 898:2004, ČSN EN ISO 13857:2008, ČSN EN 982:1997 + A1:2008, ČSN EN 55 011 ed.2:2007, ČSN EN 61000-6-4:2002 ed.2:2007, ČSN EN 60204-1 ed.2:2007

The product is safe on condition of the common and determined usage.

The conformity judging was performed according to §12, par. 3, let. a), of the Law no. 22/1997 Coll. as amended

2) ²⁾ The declaration of conformity was carried out in the cooperation with the TÜV CZ s.r.o., Novodvorská 994, 142 21 Prague 4 – Czech Republic, Identification number: 63987121 - Inspection body no. 4002

The inspection certificate no. 00.480.140/09/07/02/0 was issued.

BOMAR, spol. s r.o.
Těžební 1236/1, 627 00 Brno
Czech Republic
IČO: 48908827
DIČ: CZ48908827

Alfred Pichlmann, Managing Director



Point of issue, datum

Name and function
of the responsible subject

Signature

1) Name, address and identification number of the subject issuing the conformity declaration (producer of importer)

2) The authorized or accredited body co-operating on the conformity judging



If the equipment is installed without safety equipment offered by BOMAR, spol. s r.o. or its agents and used by the customer (or buyer) then EC declaration loses validity.
EC Declaration of conformity is valid only if customer (buyer) installed the BOMAR safety equipment with the machine or with some other with equivalent safety device in accordance with current applicable regulations and standards.
All machine elements and components that were built into the device by BOMAR, spol. s r.o. have been declared "identical" to a safety device, as offered by BOMAR, spol. s r.o. or its agents.

Content

1. SAFETY NOTES.....	7
1.1. Machine determination.....	9
1.2. Protective suit and personal safety.....	9
1.3. Safety notes for machine operator.....	10
1.4. Safety notes for the servicing and repairs.....	10
1.4.1. Safety notes for the servicing and repairs on hydraulic unit.....	11
1.5. Safety machine accessories.....	11
1.5.1. Total Stop.....	11
1.5.2. Arm covers.....	11
1.5.3. Saw band stretching and rupture inspection.....	12
1.5.4. Band saw cover.....	12
1.6. Safety notes for the cooling.....	12
1.6.1. Instructions for first help.....	13
1.7. Umístění štítku stroje / Maschinenschild position / Position of machine label.....	13
1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols.....	14
2. MACHINE DOCUMENTATION.....	15
2.1. Technická data / Technische Daten / Technical data.....	17
2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram.....	18
2.3. Popis / Beschreibung / Description.....	19
2.4. Transportation and stocking.....	20
2.4.1. Conditions for transportation and stocking.....	20
2.4.2. Transport and stocking preparations.....	20
2.4.3. Transport and stocking.....	20
2.4.4. Transportní schéma / Transport schema / Transport scheme.....	21
2.5. Activation.....	22
2.5.1. Machine working conditions.....	22
2.6. Band saw unpacking and assembling.....	22
2.6.1. Machine installing and levelling.....	22
2.6.2. Machine disposal after lifetime.....	22
2.6.3. First run of the power pack.....	23
2.6.4. Filling the reservoir with hydraulic oil.....	23
2.6.5. Kotevní plan / Verankerungsplan / Grounding plan.....	24
2.7. Electrical connection.....	25
2.7.1. Check the direction of the saw band.....	25
2.7.2. Check machine connection into electrical network.....	26
2.8. Filling of the cooling system.....	26
2.9. Check machine function.....	26
2.10. Saw band.....	26
2.10.1. Saw band size.....	26
2.10.2. Selection of the saw band tooth system.....	26
2.10.3. Saw band running-in.....	27
2.10.4. Tables for teeth selection.....	28
3. MACHINE CONTROL.....	29
3.1. Starting the band saw.....	31
3.2. Control panel.....	32
3.2.1. Control panel description.....	33
3.3. Machine setup.....	34
3.3.1. SERVIS.....	35
3.3.2. SETUP.....	36
3.4. Machine error messages.....	38
3.5. Machine control.....	39
3.5.1. Semi-automatic cycle.....	39
3.5.2. Cycle breaking.....	40
3.6. Band saw adjusting.....	40
3.6.1. Angular cut setting.....	40
3.6.2. Adjusting band guides.....	41
3.6.3. Cutting speed adjusting.....	42
3.6.4. Adjustment of pressure to the cut.....	42
3.6.5. Speed adjustment of the arm lowering.....	43
3.6.6. Saw frame lift stop setting.....	43
3.6.7. Saw arm lower position stop adjustment.....	44
3.6.8. Brush adjustment.....	44
3.7. Material insertion.....	45
3.7.1. Handling agent selection.....	45
3.7.2. Insertion.....	45
3.7.3. Bundle material cutting.....	45
4. MACHINE SERVICE.....	47
4.1. Saw band dismantling.....	49
4.2. Saw band installation.....	50

4.3. Saw band stretching and inspection.....	50
4.3.1. Saw band stretching.....	50
4.3.2. Saw band inspection.....	50
4.3.3. Saw band run setting.....	51
4.3.4. Adjusting of the limit switch of the saw band stretching.....	51
4.4. Cooling agents and chips disposal.....	52
4.4.1. Coolant device inspection.....	52
4.4.2. Chips disposal.....	52
4.5. Hydraulic, Greases and oils.....	53
4.5.1. Gearbox oils.....	53
4.5.2. Lubricant greases.....	53
4.5.3. Lubrication.....	54
4.5.4. Hydraulic oils.....	54
4.5.5. Hydraulic unit service.....	55
4.6. Machine cleaning.....	55
4.7. Worn pieces replacement.....	56
4.7.1. Pushing bearing replacement.....	56
4.7.2. Saw band guiding pulleys replacement.....	59
4.7.3. Hard metal guides replacement.....	61
4.7.4. Brush replacement.....	64
5. ZÁVADY / TROUBLESHOOTING.....	65
5.1. Mechanical problems.....	67
5.2. Electric problems.....	69
5.3. Hydraulic problems.....	70
6. SCHÉMATA / SCHEMAS / SCHEMATICS.....	71
6.1. Elektrické schéma / Elektroschema / Wiring diagram 3x400 V, TN-C, 50Hz.....	73
6.2. Elektrické schéma / Elektroschema / Wiring diagram 3x400 V, TN-C-S, 50Hz.....	93
6.3. Elektrické schéma / Elektroschema / Wiring diagram 3x230 V, TN-C, 50Hz.....	113
6.4. Hydraulické schéma / Hydraulikschema / Hydraulic diagram.....	133
7. VÝKRESY SESTAV PRO OBJEDNÁNÍ NÁHRADNÍCH DÍLŮ / ZEICHNUNGEN FÜR BESTELLUNG DER ERSATZTEILE / DRAWING ASSEMBLIES FOR SPARE PARTS ORDER.....	135
7.1. Individual 520.360 GH.....	136
7.2. Kusovník / Stückliste / Piece list – Individual 520.360 GH.....	137
7.3. Rameno / Sägerahmen / Saw arm 1.....	138
7.4. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 1.....	139
7.5. Rameno / Sägerahmen / Saw arm 2.....	140
7.6. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 2.....	141
7.7. Konzola otočná / Drehkonsole / Turnable console.....	142
7.8. Kusovník / Stückliste / Piece list – Konzola otočná / Drehkonsole / Turnable console.....	143
7.9. Sloup / Säule / Pillar – 1.....	144
7.10. Kusovník / Stückliste / Piece list – Sloup / Säule / Pillar – 1.....	145
7.11. Sloup / Säule / Pole – 2.....	146
7.12. Kusovník / Stückliste / Piece list – Sloup / Säule / Pillar – 2.....	147
7.13. Podstavec / Untersatz / Base.....	148
7.14. Kusovník / Stückliste / Piece list – Podstavec / Untersatz / Base.....	149
7.15. Svěrák / Schraubstock / Vice.....	150
7.16. Kusovník / Stückliste / Piece list – Svěrák / Schraubstock / Vice.....	151
7.17. Válec svěráku / Schraubstockzylinder / Vice cylinder.....	152
7.18. Pohon / Antrieb / Drive.....	153
7.19. Válec zvedací / Hebezyylinder / Lifting cylinder.....	154
7.20. Kusovník / Stückliste / Piece list – Válec zvedací / Hebezyylinder / Lifting cylinder.....	155
7.21. Napínání / Spannung / Tensioning.....	156
7.22. Kusovník / Stückliste / Piece list – Napínání / Spannung / Tensioning.....	157
7.23. Vedení pásu / Sägebandführung / Belt guide.....	158
7.24. Kusovník / Stückliste / Piece list – Vedení pásu / Sägebandführung / Belt guide.....	159
7.25. Vodící kostka / Führungsklotz / Guiding cube 1.....	160
7.26. Kusovník / Stückliste / Piece list – Vodící kostka / Führungsklotz / Guiding cube 1.....	161
7.27. Vodící kostka / Führungsklotz / Guiding cube 2.....	162
7.28. Kusovník / Stückliste / Piece list – Vodící kostka / Führungsklotz / Guiding cube 2.....	163
7.29. Rozvaděč / Verteiler / Distributor.....	164
7.30. Kusovník / Stückliste / Piece list – Rozvaděč / Verteiler / Distributor.....	165
7.31. Kartáč / Bürste / Brush.....	166
7.32. Kusovník / Stückliste / Piece list – Kartáč / Bürste / Brush.....	167
7.33. Regulace přítlaku / Schnittdruckregulation / Pressure into cut regulation.....	168
7.34. Kusovník / Stückliste / Piece list – Regulace přítlaku / Schnittdruckregulation / Pressure into cut regulation.....	169
7.35. Indikátor napínání / Spannungsindikator / Power indicator.....	170
7.36. Brzda / Bremse / Brake.....	171
7.37. Vedení / Bckenführung / Guide.....	172
7.38. 173	

1. **Safety notes**

The operating instructions must be read by the person, who keeps in touch with the machine before transportation, installation, using, servicing, repair, stocking or removal!

The operating instructions include relevant information. The operator must familiarise himself with the install and operation, safety notes and machine servicing, because reliability and service life must be reached. The operating instructions must avoid risks, which are linked to work on the machine. Before transporting and using of the machine, please read the instructions thoroughly!

Attention!

*The operating instructions must be available at the machine!
Keep the operating instructions in good condition!*

1.1. Machine determination

The band saw **Individual 520.360 GH** is determined for cutting and shortening of rolled bars and drawn bars and profiles from steels, stainless steels, non-ferrous metals and plastics **with cutting angle from 0° to 60°**.

Combustible materials are excepted for cutting! Any other usage and operation outside this range are unauthorized and the manufacturer/supplier does not accept any responsibility for any damages resulting from such misuse. **The operator has full responsibility!**

The machine is equipped with safety and protective guarding for operator and machine protection. Nevertheless, this safety and protective guarding cannot prevent injury. Service personnel must read this chapter and comprehend it, before he starts to work on the machine. **Always keep instructions about work safety!** Service personnel must take into account other aspects of the risk, which refer to the ambient conditions and the material.

Attention!

Consider the safety signs on the machine. Do not remove or damage them!

1.2. Protective suit and personal safety

Wear tight fitting overalls! Loose fitting clothes may be caught with machine parts and cause serious injury.

Wear protective gloves! Material cuts and saw band have sharp edges and may cause serious injuries.

Attention!

*Gloves you can use only at working material replacement (saw band)! The machine and accessories must be inactive!
If the machine is running, you must not wear gloves! It is dangerous, because some parts of the machine can catch gloves!*

Wear protective shoes with non-skid soles! The unsuitable shoes may cause balance loss and following injury. Falling work pieces may cause serious injuries too.

Wear protective goggles! Chips and cooling liquid may damage your eyes.

Always wear ear protections! Most of the machines emit up to 80 dB and may damage your hearing.

Do not wear jewellery and always tie back long hair! Moving machine parts can catch jewellery or loose hair and may cause serious injuries.

Operate the machine only when you are fit enough to work. Illnesses or injuries diminish concentration. Avoid machine work, which may compromise the safety of you and your colleagues!

1.3. Safety notes for machine operator

Attention!

*Machine can be operated by person older than 18 years!
Machine can be operated only person physically and mentally fit for this activity*

Machine can be operated only by one person. Machine operator is responsible for presence of other persons by the machine.

Keep instructions and orders about work safety!

Read the operating instructions, before you start to work on the machine! Keep the operating instructions in good condition!

Close covers before the machine starting and check, if the covers are not damaged. Damaged covers must be repaired or changed. Do not start the machine, if the cover is removed! Check, if the electric cables are not damaged.

Attention!

Do not connect the machine to electricity if the covers are removed. Do not touch the electrical equipment.

- Do not hold the material for clamping to the vice and for cutting!
- Do not operate with the buttons and the switches on the control panel, when you have gloves!
- For machine starting take care, that there is nobody in the working area of the machine (it means in the working area of the vice, the saw band, the saw arm etc.).
- In no circumstances touch the rotating elements.
- Work on the machine only when the machine is in good condition!
- Check at least once in a shift, if the machine is not damaged. If the machine is damaged, you must bring the machine in order and you must inform your superior!
- Keep your working area clean! Ensure sufficient lighting in the working area.
- Take off the spilt water or the oil from the floor and dry it. Do not touch the cooling liquid with bare hands! Do not set the nozzle of the cooling liquid, when the machine is started on
- Do not remove the chips from the working area of the machine, when the machine is started on!
- Do not use the compressed air for the machine cleaning or for the chips removing!
- Use the protective instruments for chips removal!

1.4. Safety notes for the servicing and repairs

Attention!

Only a qualified professional can carry out the servicing and repairs of the electric equipment! Take special care during the work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety! Otherwise, there is possibility of heavy injury!

Switch off the main switch and lock it, before you start service work! Otherwise, there is possibility of hazardous machine starting.

Only qualified person can do the servicing and repairs. For parts changing, use only parts, which are identical with the originals. Otherwise, there is possibility of health hazard. Use only recommended type of the hydraulic oils and oils and lubricants!

Do not remove or do not lock the limit switches or safety equipments! Any use of the saw, accessories or machine parts other than that intended by the BOMAR, spol. s r.o. company is not permitted. The guarantee on this product will be afterward lost and BOMAR, spol. s r.o. takes no responsibility for caused damages.

1.4.1. Safety notes for the servicing and repairs on hydraulic unit

Compliance with the the principles of cleanliness is basic requirement for trouble-free operation of hydraulic equipment. Hydraulic components are products made with high accuracy, and any contamination leads to a reduction lifetime or even malfunction. The consequences are very difficult to remove and expensive.

Always use clean tools. Parts and fasteners, which are part of a hydraulic circuit, never put away the dirty surface. The best cleaning agent is crepe paper, because the fibers of the cleaning cloths can also cause malfunction.

Protective cap from the threaded chamber remove just before the assembly of the unit.

Hoses and pipes before mounting flush with gasoline or other cleaning agent and blow compressed air.

All fittings must be properly tightened. However, do not raw power.

1.5. Safety machine accessories

The machine is equipped with safety accessories. It protects the operator from injuries and the machine before damage. The safety accessories are blocking accessories, emergency switches and covers. Check once in a week the function of the safety accessories. If the safety accessories are functionless, you must stop work and repair or change the safety accessories.

Enhanced risk!

Do not come into or intervene in the cutting area. Otherwise, there is possibility of heavy injury.

1.5.1. Total Stop

TOTAL STOP button is used for emergency switching – off the machine in case defect or health hazard. By pressing **TOTAL STOP** button is interrupted the supply of the electrical power.

If any damages or fault appears, immediately press TOTAL STOP button! Release the pressing button is possible by twisting of the upper part of the button.

1.5.2. Arm covers


Left cover – It covers tightening wheel. If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible start in set mode.

Right cover – It covers driving wheel. If the cover is opened during operation, the limit switch is opened and the band saw is stopped. The band saw is not possible start in set mode.

Central cover – It covers band saw.



The band saw is stated to the operation, when the covers is closed!



Two limit switches on saw arm control if covers are open or not.

1.5.3. Saw band stretching and rupture inspection


This device checks the saw band stretching and causes immediate machine shut – down in the event the band ruptures.



The device contains limit switch. Check the stretching carefully and periodically – eventually adjust.

1.5.4. Band saw cover

It covers the visible area of the saw band from left guiding cube to the frame.



Never switch on the saw band driver if this cover is not mounted!

1.6. Safety notes for the cooling


Attention!

- *When handling cooling agents always wear hazardous fluid-proof gloves!*
- *Wear protective goggles!*
- *Cooling liquid can get in contact with your eyes and may cause permanent severe injuries*

1.6.1. Instructions for first help

1. Pull off and safely remove polluted, soaked clothing.
2. For breathing, go out in the fresh air or look for first aid treatment.
3. Wash with water or use crèmes for contact with the skin.
4. Flush with water for eyes and look for first aid treatment.
5. For swallowing, drink a lot of water and induce vomiting. Look for medical help.


1.7. Umístění štítku stroje / Maschinenschild position / Position of machine label




Machine label is placed on saw arm between pile and saw band drive.


1.8. Umístění bezpečnostních značek / Verteilung der Sicherheitszeichen / Position of safety symbols

HV
Hlavní vypínač
Hauptschalter
Main switch







A




SP:
Směr pohybu
Bewegungsrichtung
Direction of motion




B




PO:
Noste pevnou pracovní obuv
Tragen Sie Sicherheitsschuhe
Wear fixed protective shoes




CZ:
Přečíst návod k použití
Bedienungsanleitung lesen
Read the operating instructions




OBS:
Noste ochranné brýle a sluchátka
Tragen Sie eine Schutzbrille und
Gehörschutz
Wear protective goggles
and headphones




NE
Nebezpečí úrazu
elektrickým proudem
Verletzungsgefahr vom
elektrischen Strom
Electrical hazard





NR:
Nebezpečí zachycení
Erfassungsfahr
Trampling hazard



NS
Nebezpečí stlačení
Pressungsgefahr
Crushing hazard








2. **Machine documentation**

2.1. Technická data / Technische Daten / Technical data

Hmotnost stroje / Maschinengewicht / Machine weight:				
• Hmotnost / Gewicht / Weight	1400 kg			
Rozměry stroje / Maschinengröße / Machine size :				
• Délka / Länge / Length	2350 mm			
• Šířka / Breite / Width	2450 mm			
• Výška / Höhe / Height	2100 mm			
Elektrické vybavení / Elektrische Ausrüstung / Electrical equipment:				
• Napájení / Versorgungsspannung / Supply voltage	~3 x 400 V (230 V), 50Hz, TN-C-S/TN-C			
• Příkon / Gesamtschlosswert / Total Input	5,2 kW			
• Max.jištění / Max. Vorschalticherung / Max. Fuse	16 A			
• Krytí / Schutzart / Protection	IP 54			
Akustický tlak / Schalldruckpegel / Acoustic pressure:				
• Individual 520.360 GH	$L_{Aeqv}=76,3$ dB			
Pohon / Atrieb / Drive:				
• Typ / Typ / Type	BN112M4			
• Napájení / Versorgungsspannung / Supply voltage	~3 x 400V, 50Hz			
• Výkon / Leistung / Output	3 kW			
• Jmenovité otáčky / Motornendrehzahl / Nominal speed	1440 min ⁻¹			
Hydraulické zařízení / Kühlmiteleinrichtung / Hydraulic equipment:				
• Typ / Typ / Type	SSM-3/79+76+16-1/3-17/02400			
• Výkon / Leistung / Output	3 kW/8 MPa			
Chladicí zařízení / Kühlmiteleinrichtung / Cooling equipment:				
• Typ / Typ / Type	3-COA4-12			
• Výkon / Leistung / Output	0,05 kW			
• Obsah nádrže / Volumen vom Kühlmittel / Capacity	35 l			
Rozměr pásu / Sägebandedimension / Band size:				
4780×34×1,1 mm				
Řezná rychlost / Schnittgeschwindigkeit / Cutting speed:				
20–120 m/min. (special 10-70 m.min⁻¹, 20-120 m.min⁻¹)				
Řezné rozsahy / Schnittbereiche / Cutting size:				
				
0°	Ø360 mm	520×360 mm	360×520 mm	360×360 mm
45° R	Ø360 mm	355×325 mm	360×315 mm	350×350 mm
60° R	Ø250 mm	325×235 mm	360×215 mm	235×235 mm

Warning:



If the material detection device is installed on machine maximal workpiece height is 10 mm shorter.

Level of acoustic pressure:


Equivalent level of acoustic pressure A (noise) at operator position are $L_{Aeqv}=76,3$ dB. Mentioned values are levels of emission which doesn't have to represent safe levels. Factors which influence real level of acoustic pressure on machine operator are: working place characteristics, cut material, saw band. These factors have significantly influence on acoustic pressure.

2.2. Rozměrové schéma / Aufstellzeichnung / Installation diagram

	A	B	C
Individual 520.360 (D)GH	2350	2450	2100
Individual 620.460 (D)GH	3000	3200	2350
Individual 720.540 (D)GH	3250	3550	2420
Individual 820.640 (D)GH	3750	4050	2700



2.3. Popis / Beschreibung / Description



2.4. Transportation and stocking

2.4.1. Conditions for transportation and stocking

Keep recommendations for the manufacturers for transportation and stocking! If the recommendations are not kept, damage can occur to the machine.

- Don't use a forklift truck for handling the machine, if you do not have license for it!
- Don't move under suspended loads! Fault in lifting device may cause serious injury.
- Keep a safe distance from the machine during the transport.
- Temperature of the air from -25°C to 55°C , for a *short term* (max. 24 hours) temperature of the air until 70°C
- Do not expose the machine to radiation (for example microwave radiation, ultraviolet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.
- Take measures, to prevent damage by dampness, by vibrations and by shakes.

2.4.2. Transport and stocking preparations

Close the vice and thoroughly oil all blank surfaces.

Lower the saw frame to the lowest position.

Make sure to empty the machine of all traces of the cooling agent.


Fasten all loose parts securely to the machine.

Pack and wrap the control desk securely to avoid damage during transport.

Fix the stickers stating the minimum approximate machine weight to at least five well visible places.

2.4.3. Transport and stocking


The machine must be secured during transportation. Screw on the palette to the floor of the van or the trailer. Be careful that the machine is not damaged during transportation. Store the machine only under conditions mentioned in the manual, to avoid damage of the machine.




It is forbidden to handle the machine any other way, than it is written in this operating instructions, the machine can be damaged.

2.4.4. Transportní schéma /
Transport schema /
Transport scheme

	A	B	C	X
Individual 520.360 (D)GH	2400	1695	1950	1200
Individual 620.460 (D)GH	3100	1695	2260	1200
Individual 720.540 (D)GH	3300	1930	2430	1225
Individual 820.640 (D)GH	3600	1930	2600	1225



Místo pro lyžiny
vysokozdvížeňého vozíku
Die Stelle für Greifen mit
der Gabel des Gabelstaplers
Place for forklift's skides



2.5. Activation

2.5.1. Machine working conditions

Keep the conditions of the manufacturer for machine operating! If recommendations are not kept, damage can occur to the machine.

The manufacturer warrants the correct function of the machine for these conditions:

- At temperature air from **5°C to 40°C**, the temperature average during 24 hours must **not exceed over 35°C**.
- At relative dampness of the air in the interval from 30% to 95% (not concentrate). Altitude must be lower than 1000 metres.
- Do not expose the machine to the radiation (for example microwave radiation, ultra-violet radiation, laser radiation, x-ray radiation). Radiation can cause problems with the machine function and deteriorating condition of the isolation.

Attention!

If the ambient temperature drops below 15 ° C is required before operating the machine to have switch on hydraulic unit around 10 minutes and then made several motion few times (for example, in manual mode) by all hydraulic cylinders. The reason is to heat hydraulic oil to the operating temperature for proper function of the pressure switches (and choke).

2.6. Band saw unpacking and assembling

Remove the packing from the machine and unpack all parts.

Attention!

Switch off the main switch and lock it, before you start assembly! Otherwise, there is possibility of hazardous machine starting.

If the hydraulic unit is outside the machine (the machine only connected hoses and cables), it needs to be placed and mounted on a solid basis (floors, etc.). The mounting holes are used on the bottom (bases) of the tank.

2.6.1. Machine installing and levelling

Check the floor supporting capacity before machine installing. If the floor capacity does not agree with requirements, you must prepare the necessary base for the machine.

Minimal requirement:

machine weight – Individual 520.360 GH – 1400 kg

+ weight of accessories

+ maximum weight of material

- The machine must be levelled at the horizontal position. All feet of the machine must touch with the floor after levelling
- The machine must be levelled by means of the calibrated spirit level. Spirit level is put on the vice area. Set the roller conveyors according to the spirit level.
- For machine levelling, take care that there is sufficient available space for operation, repair work, servicing of the machine and handling the material..
- The machine including appended parts and accessories must be visible from the place of operation.

2.6.2. Machine disposal after lifetime

Blown out all service fluids (cooling liquid, hydraulic oil) into designated reservoir. Dismantle machine into separate parts and dispose them in accordance with valid directives.

2.6.3. First run of the power pack

Before the first run check:

- The direction of the Pump, while run the power pack for max. 2seconds.
- The cooling fan of the motor has to rotate in the same direction as the arrow on the top of the motor cowling indicates.
- In case of wrong rotational direction, the electrical phase in the connection box is to be changed. This check is required after every disconnection from the power source
- Wiring matches with electrical and hydraulic diagrams
- the electric motors (pump and cooler) are properly connected and have the prescribed rotation
- the hydraulic accumulator with nitrogen gas to the specified value
- aux. elements work right (thermometer, level gauge, heater)

First run (Attention – working pressure on securing valve is set by producer in accoring the hydraulic diagram):

- In the short intervals activate an electric pump
- check for leaks and noise
- Bleed the hydraulic circuit
- if possible, test the circuit function with minimum load
- test the electrical equipment
- during operation monitor measuring equipment, noise, height and temperature of oil in the tank
- During this time a careful bleeding off for the whole hydraulic system is necessary. In case there is no bleeder port, the power pack will bleed itself after a while via the air breather on the tank or the return line filter.
- After multiple start-up.

2.6.4. Filling the reservoir with hydraulic oil

Oil regulations and recommendations of the manufacturer in the technical documentation (appendix) are to be carefully observed. For standard power packs we recommend the oilyte OH-HM32 (DIN 51524) of all known oil manufacturers.

Power packs have to be filled up with clean, pre-filtered oil! The purity of the hydraulic fluid must correspond to the class 10 NAS 1638 (reachable with filter $\beta = 75$)!


Filling from container, such as barrels, buckets, etc. is not recommended or permitted!

The maximum oil level will be shown on the upper marking at the dipstick or the sight level glass. Overfilling has to be prevent. The maximum filling rate of 15 l/min shouldn't be exceed.

Oil type	Kinematic viscosity ν in mm^2/s in relationship to the fluid temperatur					Freezing point °C
	0°C	20°C	40°C	60°C	80°C	
OH-HM 32	220	100	32	15	7	-40
OH-HM 46	400	170	46	18	11	-30
OH-HM 68	700	170	68	26	14	-28
OH-HV 32	180	67	32	17	11	-40
OH-HV 46	350	110	46	25	14	-36

2.6.5. Kotevní plan / Verankerungsplan / Grounding plan

	A	B	Příkon Gesamtschlusswert Total Input [kW]	Max.jištění Max. Vorschaltsicherung Max. Fuse [A]	Únosnost podlahy Vorschaltsicherung Carrying capacity [kg/m ²]
Individual 520.360 (D)GH	1114	1164	5,2 kW	16	1100
Individual 620.460 (D)GH	1114	1164	8,7 kW	32	1500
Individual 720.540 (D)GH	1107	1482	8,7 kW	32	1700
Individual 820.640 (D)GH	1107	1482	10,5 kW	32	2000



Kotvicí materiál / Verankerungsmaterial / Grouding material

- 4x Hmoždina / Dübel / Plug – Ø18 mm
- Vrtáno do hloubky / In die Tiefe gebohrt / Drilled to – 140 mm
- Šrouby / Schraube / Screws – M16

- Šrouby podložit deskami o min. rozměrech P10×100-100
- Die Schrauben mit Platten mit Minimaldimensionen P10×100-100 unterlegen
- Screw must be bottomed with plates (min. dimensions P10×100-100)

Požadavky na rovinnost podlahy / Anforderungen an die Bodenebenheit / Requirements for floor flatness

± 10 mm / 1 m

2.7. Electrical connection

Attention!

Only a qualified professional must carry out the servicing and repairs of the electric equipment! Take special care during work with electrical equipment. High voltage shock can have fatal consequences! Always keep notes about work safety.

Electrical parameters of the machine:

- Service voltage: $\sim 3 \times 400 \text{ V (230 V) 50 Hz, TN-C/TN-C-S}$
- Total input/ Max. fuse: $5,2 \text{ kW / 16 A}$

Before connecting switch off the main switch of the power supply circuit for the machine and ensure dry place when doing connecting works!

Service voltage must agree with the line voltage! Crosscut of the supply line must respond with rated current for max. machine load.

Note:

The values of the crosscut of the conductor and the rated current are in the norms.

Note:


The socket with the fork can be used only at the machines with the rated current less than 16 A and total input less than 3 kW.

In case the machine is connected with a direct connection, an extra main switch must be added which can be locked in zero position.

Attention!

In this case the extra main switch becomes primary and the main switch on the machine has only secondary function.

2.7.1. Check the direction of the saw band



After the machine has been successfully connected, briefly switch on the machine and put the driving engine of the band in the running position. The direction must be in accordance with the arrow direction on the saw band cover. In case the direction of the saw band does not match, two phases at the terminal strip must be switched.

2.7.2. Check machine connection into electrical network

Attention!

When you connect the machine to the electrical network observe correct connection of all phases!

ENGINE IN IN HYDRAULIC AGGREGATE CANNOT BE OPERATED WITH REVERSE TURNING MORE THEN 10 SECONDS!!!

2.8. Filling of the cooling system

Prepare the mixture of the water and the cooling liquid. Keep the concentration specified by manufacturer. Shift away the cover from the drainage hole. Fill the mixture of the water and the cooling liquid to the tank of the cooling system. Area of the tank for the cooling liquid is discovered from the chapter *Technical data*.

Let the drainage hole opened and with the sieve during operation, because it secures the right work of the cooling system. Filling the tank with the cooling liquid, take care that the liquid does not drip out of the tank and the tank does not overflowed.

Note

If the machine is equipped with Micronising unit, fill the Microniser container with prescribed cooling agent. Microniser is ready for operation.

2.9. Check machine function

Check, if the machine or some parts of the machine were not damaged during transport.

Check, if covers are installed and functional. Check by means of the Tenzomat if the saw band is correctly stretched. If it is necessary, you can stretch the saw band according to chapter *Selection and replacement of the saw band*. Values of the saw band stretching are on the Tenzomat. Switch on the main switch and check the motors and systems (saw band drive, hydraulic pump, cooling pump, chips conveyor).

Open and close the main vice. Turn the saw frame of the band saw from one outer position to other outer position. Raise the saw frame to the top position and drop the saw frame to the lowest position.

Start the machine with the cooling pump and let it run without load until the cooling system will be filled with cooling liquid. As soon as the cooling liquid starts to escape from the nozzles of the cooling system, the cooling system is ready for the operation. Carry one cycle of cutting without material. Check, if the machine runs with no irregularities. If all machine functions are right, the machine is ready for operation..

2.10. Saw band

Refit the saw band cover only after you have installed and tightened the saw band.

2.10.1. Saw band size

4780×34×1,1 mm

2.10.2. Selection of the saw band tooth system

The manufacturers provide the saw bands with constant and variable tooth system. The important factor for selection of the tooth system is length of the cutting canal with respect to the size of the product

1. *Constant tooth system* – the saw band has parallel tooth pitch all over length. This way is suitable for cutting of solid material.

BOMAR recommended Variable tooth system for band saw.



2. *Variable tooth system* – tooth pitch is variable. Variable tooth system is used for profiled materials and bundle cutting. Variable tooth pitch lowers vibration of the saw band, increases service life of the saw band and quality of the cutting area.

In tables, there are advised type of the tooth system depending on sizes and form of the cutting material.

Footnotes:

Z₁Z₂ – teeth number on one inch S – tooth with zero angle of the teeth K – tooth with positive angle of the teeth

Examples of the tooth system marking:


32 S – number „32“ means 32 teeth on one inch (that means constant tooth system), letter „S“ marks teeth with zero angle of the tooth.

4–6 K – number „4–6“ means 4 till 6 teeth on one inch (that means variable tooth system); letter „K“ marks teeth with positive angle of the teeth.

2.10.3. Saw band running-in















Running-in: Cut the material with the frame lowering reduced to 50% only. When vibrations occur increase or decrease the band speed.

When cutting small pieces run the band until approximately 300 cm² of material has been cut. When cutting large pieces run the band for 15 minutes approximately. When the band has been run, increase the lowering-speed to normal speed. The running in of the saw band avoids micro-breaks on the cutting edges of new saw band ensuing from first excessive stress. This would decrease service life substantially. The optimal running in of the saw band produces ideal rounded cutting edges and therefore the conditions for an optimal service life.



Note: Run regrinding saw bands too.

2.10.4. Tables for teeth selection

SHAPED MATERIAL ($D_p, S = \text{mm}$)						
						
Note: Table shows tooth system selection for cutting one piece of the profile. For cutting of more pieces of the profiles (bundle), you must think of the size of the wall as double size of the wall of one profile (that means, size „S“ equates to 2xS). In table, there are tooth systems constant and variable.						
Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	20	40	60	80	100	120
2	32 S	24 S	18 S	18 S	14 S	14 S
3	24 S	18 S	14 S	14 S	10-14 S	10-14 S
4	24 S	14 S	10-14 S	10-14 S	8-12 S	8-12 S
5	18 S	10-14 S	10-14 S	8-12 S	6-10 S	6-10 S
6	18 S	10-14 S	8-12 S	8-12 S	6-10 S	6-10 S
8	14 S	8-12 S	6-10 S	6-10 S	5-8 S	5-8 S
10	-	6-10 S	6-10 S	5-8 S	5-8 S	5-8 S
12	-	6-10 S	5-8 S	5-8 S	4-6 K	4-6 K
15	-	5-8 S	5-8 S	4-6 K	4-6 K	4-6 K
20	-	-	4-6 K	4-6 K	4-6 K	3-4 K
30	-	-	-	3-4 K	3-4 K	3-4 K
50	-	-	-	-	-	3-4 K
Size of the wall S [mm]	Tooth system (Z_p, Z) Outer diameter of the profile D_p [mm]					
	150	200	300	500	750	1000
2	10-14 S	10-14 S	8-12 S	6-10 S	5-8 S	5-8 S
3	8-12 S	8-12 S	6-10 S	5-8 S	4-6 K	4-6 K
4	6-10 S	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K
5	6-10 S	5-8 S	4-6 K	4-6 K	4-6 K	3-4 K
6	5-8 S	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K
8	5-8 S	4-6 K	4-6 K	3-4 K	3-4 K	3-4 K
10	4-6 K	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K
12	4-6 K	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K
15	4-6 K	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K
20	3-4 K	3-4 K	2-3 K	2-3 K	2-3 K	2-3 K
30	3-4 K	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K
50	2-3 K	2-3 K	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K
75	-	2-3 K	1,4-2 K	1,4-2 K	1,4-2 K	0,75-1,25 K
100	-	-	1,4-2 K	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
150	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
200	-	-	-	0,75-1,25 K	0,75-1,25 K	0,75-1,25 K
SOLID MATERIAL ($D = \text{mm}$)						
						
Constant tooth system				Variable tooth system		
length of the cut D	tooth system (Z, Z)		length of the cut D	tooth system (Z, Z)		
to 3 mm	32		to 30 mm	10-14		
to 6 mm	24		20-50 mm	8-12		
to 10 mm	18		25-60 mm	6-10		
to 15 mm	14		35-80 mm	5-8		
15-30 mm	10		50-100 mm	4-6		
30-50 mm	8		70-120 mm	4-5		
50-80 mm	6		80-150 mm	3-4		
80-120 mm	4		120-350 mm	2-3		
120-200 mm	3		250-600 mm	1,4-2		
200-400 mm	2		500-3000 mm	0,75-1,25		
300-800 mm	1,25					
700-3000 mm	0,75					

3. **Machine control**

3.1. Starting the band saw

- » 1. Switch on the main switch of the band saw. The main switch is situated on the side of the switchboard.




2. Switch on the safety circuit of the band saw **Safety circuit** (button **2**) on control panel of the band saw.














3.2. Control panel

Ovládání stroje
Bedienung der Maschine
Machine control



3.2.1. Control panel description

<p>1</p>	<p>LCD Display On to display are described all running processes, control with functional buttons F1-F4</p>
<p>2</p>	<p>Control buttons / numeric keypad</p>
	<p>GH version – no function DGH version – vice movement right/left</p>
	<p>Clamp / release vice clamp</p>
	<p>Clamp / release vice In manual cycle pressing and holding the button allows you to release pressure or clamping vise.</p>
	<p>Cooling system selection Cooling with Microniser (optional accessories) Cooling with water cooling pump runs even when the saw band drive is switched off.</p>
	<p>Movement of the arm Pressing and holding a button or trigger arm lifts the lifting hydraulic cylinder. When lifting the arm using the arm can be lifted in its entirety lifting cylinder. On the down can be activated by simultaneously pressing the rapid move functional button F1.</p>
	<p>No function</p>
	<p>Turn on / off the band drive In manual mode the button is displayed "I" switched band drive, the button with the symbol "0" switch off</p>
	<p>Turn on / off the hydraulic circuit Button with the symbol "I" turns the hydraulic circuit, the button with the symbol "0" disables the hydraulic circuit. The hydraulic circuit is automatically switched on when needed.</p>
<p>3</p>	<p>Safety circuit Switch on the safety circuit by pressing button.</p>
<p>4</p>	<p>Button START - Switch on the semi-automatic cycle After pressing the button will start the cutting cycle</p>


5	Selecting a mode machines  for servicing and settings  manual mode  semi-automatic mode
	Note: The functions performed in both manual and semi-automatic mode are the same, but only in semi-automatic cycle it is possible to use the START / STOP (ie start / off cycle)
	6 Button STOP - Switch off on the semi-automatic cycle After pressing the button will turn off the interruption or of cutting cycle
7	TOTAL - STOP button In emergency causes the machine must be immediately switched off.
8	Frequency convertor Turn to change the speed of the saw band in the range of 20-120 m / min
9	Cutting pressure manometer Pointer to cut pressure adjustment
10	Cutting pressure regulation Adjust the arm pressure to the cut.
	Note: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.
11	Governing valve for adjust the speed of the arm sinking to the cut Adjust the speed of the arm sinking to the cut by governing valve.
	Note: If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.3. Machine setup

Machine setup mode is activated by switch on control panel. Switch must be in "0" position.




After swiching into position "0" is displayed on LCD this screen.







3.3.1. SERVIS

After pressing the **F1** functional key can be set servis parameters that are password protected (947).




Control and movement in SERVIS can be set using the function keys **F1 - F4**.

On display	Description
	<p>Blade speed correction</p> <ul style="list-style-type: none"> • Constant for calculation of blade speed display values from analog input. • F1 go back, F4 next menu screen, F2 enter value
	<p>Sensor</p> <ul style="list-style-type: none"> • Display variable sensor arm (optional accessories) • Use to check the functionality of the sensor on the arm • Read only • F1 go back, F4 next menu screen
	<p>Vice clamping time</p> <ul style="list-style-type: none"> • Watch vice clamping time in ms. • F1 go back, F4 next menu screen, F2 enter value
	<p>The type of machine.</p> <ul style="list-style-type: none"> • Display the machine type (the value set by the manufacturer) • Read only

3.3.2. SETUP

After pressing the **F4** functional key can be set setup parameters that are not password protected.



Control and movement in SETUP can be set using the function keys **F1 - F4**.

On display	Description
	<p>Finish of cycle</p> <ul style="list-style-type: none"> At the top – arm after cut starts above the material and cutting cycle ends At the bottom – arm after cut remains in the lower position, the above material does not exit F1 go back, F4 next menu screen, F2 enter value
	<p>Turn off motor after cut</p> <ul style="list-style-type: none"> Up position – saw arm move up after cut and then turn off drive of saw blade. Down position – drive of saw band turn off immediately after cut. F1 go back, F4 next menu screen
	<p>Upper vice</p> <ul style="list-style-type: none"> Allows to able / disable the upper vice in the cutting process F1 go back, F4 next menu screen, F2 enter value
	<p>Vice opening time</p> <ul style="list-style-type: none"> Watch vice opening time in ms. F1 go back, F4 next menu screen, F2 enter value



Upper vice opening time

- Watch upper vice opening time in ms.
- **F1** go back, **F4** next menu screen, **F2** enter value



Switch off hydraulic

- Setting the hydraulic unit off when idle machines
- **F1** go back, **F4** next menu screen, **F2** enter value



Language

- Choose menu language
- **F1** go back, **F4** next menu screen, **F2** enter value



Displaying of speed





- Displaying of band speed according to the selected units (m / min or ft / min)
- **F1** go back, **F4** next menu screen, **F2** enter value

3.4. Machine error messages

Error	Information
<p>SAFETY BUTTON is OFF</p> <p>F1 F2 F3 F4</p>	<p>Safety button (pos. 2 on kontrol panel) is not ON. Press F4 to confirm error.</p>
<p>TOTALSTOP pressed</p> <p>F1 F2 F3 F4</p>	<p>Total Stop button is active. Turn button TOTAL STOP according to the arrows. Press F4 to confirm error.</p>
<p>Blade tension faulty</p> <p>F1 F2 F3 F4</p>	<p>Saw blade in properly tensioned. Press F4 to confirm error.</p>
<p>Faulty motor protec.</p> <p>F1 F2 F3 F4</p>	<p>Engine temperature protection is active. Do not overload saw! Press F4 to confirm error.</p>

3.5. Machine control


3.5.1. Semi-automatic cycle

1. Lift the saw arm to the top position by pressing button 
2. Open the vice by pressing button 
3. Clamp material to the vice by pressing button 
4. Lower the frame about 10 mm above the material by button 

Attention!

Do not move the saw frame to the material, when the saw band driving is not running! Do not move the saw frame to the material with accelerated motion! The saw band can be damaged!

5. Select the max. height of the arm with limit switch.

You can clear the register of the performed cycles by button  and stop on 5 seconds.

6. Press button **START** (position **4**) of semi-automatic cycle.


Set the saw band speed according to the kind of the cutting material.

Set the speed of the arm sinking by adjust governing valve (position **10**).

Attention!

Press button „5“ (STOP of semi-automatic cycle). In risk of injury or damage of the band saw, press the emergency button TOTAL STOP „10“!

7. The band saw clamps the material to the vice and it makes the cut.

8. Open the vice. If the vice is not opened, you can open it by button  **6**
Remove the blank ((cut off a piece of material).
9. You can repeat whole process.

3.5.2. Cycle breaking

- »
- **STOP button**
Semi-automatic cycle is interrupted by pressing button **STOP** (position **6**) of the semi-automatic cycle.
The arm is lifted to the top position and the saw band drive is stopped.
By pressing button **START** (position **4**) of the semi-automatic cycle, you can start the cycle.
 - **TOTAL STOP button**
In case of the risk, press button **TOTAL STOP** (position **7**).
After pressing **TOTAL STOP** button, saw band drive is immediately broken and the arm sinking is stopped.
 - **Reactivation**
 1. Turn button **TOTAL STOP** according to the arrows (on the button).
 2. Switch on the **Safety circuit** by button (position **3**).
 3. By pressing button **START** (position **4**) of the semi-automatic cycle, you can start the cycle. The arm is lifted to the top position and the saw band starts the cycle.

3.6. Band saw adjusting


3.6.1. Angular cut setting

The machine enables angular cuts under **+60°**. The cut angle can be set fluently from **0°** to **60°**.

1. Release securing lever of the console.



2. Swivel the frame to the desired angle by pulling the saw arm. Angle is shown on scale (see arrow)



3. After cutting angle setup tighten securing lever.

Attention!

Moving parts of the vice must be moved when saw arm has zero angle of rotation and closed vice jaws.

Moving vice jaw of vice must be in endmost position otherwise there is a danger of collision saw arm with vice.

Electronic admeasurement (252.178/252.177) – optional accessories:



Desired cutting angle is shown on LCD. How to use electronic admeasurement is described in special instruction manual.

3.6.2. Adjusting band guides

If you want to achieve a smooth and precise cut, it is helpful to position the guide cube as close as possible to the material.




1. Press button **STOP** (pozice **6**) to switch off the hydraulics and stop on 2 second.
2. Release the stopping lever of the listel (see picture).
3. Move the left part of the guide apparatus so that the left guide cube edge is as close to the cut material as possible.
4. Tighten the lever of the gib and check the guide cube setting for possible collision with binding table or vice jaw.

Note:

Position of the guiding cubes is secure by the limit switch. The limit switch is activated after switch lever hits the listel.

3.6.3. Cutting speed adjusting



Speed of the saw band is possible change from **20 to 120 m/min**. You can effect to adjusting speed of the saw band following.

Use the frequency converter by button **8** (position on control panel) to adjust requested speed of the saw band. You can see the speed on display. Band speed is displayed on the screen **1** (position on control panel) during one semi-automatic cycle.

3.6.4. Adjustment of pressure to the cut

The band saw **Individual 520.360 GH** is equipped with cutting pressure regulation on the both guiding cubes.


Pressure adjusting is performed with governing valve **11** (position on control panel). The pressure to the cut is displayed on the cutting pressure manometer **9** (position on control panel).



Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

Lower pressure to the cut – turn the wheel against the clock's direction.



Higher pressure to the cut – turn the wheel to the clock's direction.

3.6.5. Speed adjustment of the arm lowering

Set the speed of the arm lowering to the cut by control valve for Cutting pressure regulation **10** (position on control panel).

- Set the lower speed of the arm lowering to the cut by turning the switch clockwise.
- Set the higher speed of the arm lowering to the cut by turning the switch anti-clockwise.

Notice:

If you keep closing the throttle valve too tightly, the valve seat may wear off which causes its leakage. Therefore, close the valve always gently.

3.6.6. Saw frame lift stop setting


Notice:


Arm Position is monitored by a limit switch. If the limit switch lever hits the bar and goes, then you can not run a semi-automatic cycle.

If you want to shorten the time of operations in automatic cycle, you have to adjust the height of the saw arm according to the height of the cutting material.



1. Height adjustment is sensed by a limit switch

2. Press button  and lift the saw arm to the upper position.

3. Insert a material into the vice. Carefully lower the saw arm button  to the material.

4. Stop the saw arm 10mm above the material.
5. The lift stop setting is sensed by the limit switch

Set the stop just above arm height sensor - slide stop turning the locking knob close to the limit switch

3.6.7. Saw arm lower position stop adjustment


The lower stop limits the lowest position of the saw arm. This stop point has to be checked at least once a month. If the lower stop point is wrongly adjusted, the cutting table can be deeply cut or the material will not be cut completely.



Adjusting of the saw arm lower position stop is adjusted by adjustable excenter on saw arm pile.

3.6.8. Brush adjustment

The brush for chip removal from the saw band influences cutting durability, saw band lifetime and wheels lifetime, hard metal guides and finally the cut accuracy. Brush adjustment must be checked every shift.



1. Release the fixative screw of the brush. It is possible to move with the brush.
2. Set the brush to the saw band according to the picture.

Attention!

*The brush **must not** touch the bottom of the saw teeth!*

3. Tighten the fixative screw.
4. In case, that the brush is not turned right (driving wheel slips on the driving wheels of the saw band), push by means of the screw (see arrow) driving wheel of the brush to the driving wheel of the saw band.

Attention!

*The screw **must not** be tightened with heavy force, because driving wheel of the brush can be damaged or the lifetime of the bearings of the driving wheel of the band can be lowered!*

3.7. Material insertion

- Never walk under a suspended load!
- Never climb onto the gravity-roller conveyor!
- Do not hold the material for clamping material to the vice! The vice can cause injury!

3.7.1. Handling agent selection


- Use the strong handling agents to lift and transfer the material!
- Handle with the material only with the lift truck or use the suspension strands and the crane!
- Do not use the lift truck or crane in case that you do not have the license to handle with it!

3.7.2. Insertion

Insert material to the vice and ensure that the material cannot move in the vice or fall from the vice after the clamping. If you cut long pieces of the material (for example rod, tube), you must use the roller conveyors for material shifting to the band saw. Contact Bomar for more information about roller conveyors

Make sure the conveyor is long enough and the material cannot tip off the conveyor.

Be especially careful with round materials that it always stays on two vertical rollers and that it cannot fall off the conveyor!



3.7.3. Bundle material cutting




If you want to cut the material in the bundle, there are suggestions for the positioning of bundles

Round material bundle: Take care especially with round material that the bars are put according to the picture. If the bars are put differently, you may have problems with movement.

Always weld the material at the rear end of the bundle to secure it from moving.

Before welding always, switch the machine off at the main switch! The magnetic fields, which often occur during welding, may damage the controls!

Square material bundle:



Attention:

Not all material shapes are suitable for bundle cuts. Keep the recommendation of your supplier of the saw bands for material insertion to the bundle.


4. **Machine service**

4.1. Saw band dismantling

1. Press button **8** to lift the saw arm to maximum position.
2. **STOP hydraulic** with button **5**.



3. Open all three covers on the saw arm.



4. Dismantle left protective cover of the band (arrow). Cover is fastened by screws..
5. Release the screw holding the brush. Turn the brush to the side



6. Turn by stretching star to the left side, release saw band stretching and pull down the saw band from the wheels.



7. Pull down the band from the wheels.
8. Pull up the saw band from the guiding cubes.

4.2. Saw band installation


1. Prior to installation, clean all track wheels, guide cubes and inner side of the arm thoroughly of all traces of chips and dirt. *Keep in mind the teeth direction when installing the saw band.*
2. Insert new saw band in the guide cubes. Make sure the saw band runs between both guide rollers and it is pushed all the way to the top.
3. Put the saw band on both guide wheels. Make sure that the saw band ridge fits tightly to the wheel rim. Then push the saw band as far back as possible.
4. Stretch the saw band by means of the screw, that the band did not falls from wheels.
5. Install yellow protective cover of the band.
6. Move the brush to the saw band. Tighten the securing screw.
7. Close the covers of both driving wheels.
8. Saw band installation is finished.

4.3. Saw band stretching and inspection

Right saw band stretching is one of the most important criteria's, which influents accuracy and saw band service life. Stretch the saw bands according to the selected saw band and the band saw. Keep the recommendation of your manufacturer.

4.3.1. Saw band stretching

- Switch on the hydraulic aggregate after the saw band installation check the saw band stretching on the manometer (arrow 1).



- Use the screw (arrow 2) to stretch the saw band until it is stretched to the recommended value.

4.3.2. Saw band inspection

Check the saw band in the guiding cubes and on the wheels

1. Check, if the saw band is right in the guiding cubes..
2. Switch on the saw band drive and then after 10 seconds switch off saw band drive. If the saw band drive is not possible to switch on, set the limit switch of the saw band stretching.
3. Switch off the main switch.
4. Open cover(s) of the wheels and check position of the saw band on the both wheels..
 - If the distance between backside of the saw band and the offset wheel is **1 mm**, setting is right..
 - If the distance is bigger than **1 mm**, or the saw band is on the offset of the wheel, set the saw band.
5. Close cover of the saw band.

4.3.3. Saw band run setting



Saw band run is set with screw (arrow) in the stretching cube on the saw arm. Right distance rear part of the saw band from wheel rim is **1 – 3 mm**.

- Turn with the screw to the right, the saw band is closer to the stretching wheel rim.
- Turn with the screw to the left, the saw band is far from the stretching wheel rim

Check saw band run adjustment again.

4.3.4. Adjusting of the limit switch of the saw band stretching

After the saw band is replaced, the saw band stretching must be checked. If the limit switch is not adjusted correctly, the band is stretched too little or too much.



- Tighten the saw band by means of the TENZOMAT on the optimal value (table is on the Tenzomat).



- If the drive engine is switched on, but it is not running, turn with the screw clockwise, until the engine begins run..
- If the drive engine is possible switched on, turn with the screw anticlockwise, until the engine is stopped and then turn with the screw clockwise, until the engine begins run.

4.4. Cooling agents and chips disposal

The quality of the cooling agent will deteriorate due to:	If the solution is too weak:	If the solution is too strong:
<ul style="list-style-type: none"> • use of contaminated water • impurity • outside oil contamination (hydraulics, gears) • high operating temperatures • lack of air circulation • wrong concentration 	<ul style="list-style-type: none"> • corrosion protection is diminished • lubrication decreases • microbial attack is more likely 	<ul style="list-style-type: none"> • the cooling ability is decreased • foam behaviour increases • emulsions stability deteriorates • sticky residue develops

4.4.1. Coolant device inspection

The state of the cooling agent has significant influence on the cutting quality and on the operational life of the machine. Lifetime of the cooling liquid is 1 year, after this time we recommend change the cooling liquid. This time is dependent on the degree of pollution cooling liquid (especially with oils) and on the other factors.

Check level of the cooling liquid and function of the pump periodically!

Note:

If the state of the cooling liquid is not satisfactory, the cooling liquid must be changed.

Check the state of the cooling agent according to the following table:

Testing	Interval	Method	Condition	Precaution
Liquid level	daily	visually	too low	after concentration check, refill with water or emulsion
Concentration	daily	refractometer densimeter	too high too low	refill water refill base emulsion
Smell	daily	by sense of smell	unpleasant smell	good ventilation, add biocides or renew coolant
Contamination	daily	by sense of smell	visible oil leaks, sludge fungi	surface cleaning, fix leaks, add biocides or fungicides, or coolant renewal after added system cleanser*
Corrosion-protection	when necessary	visually chip test Herbert-test	insufficient corrosion protection	test stability, if necessary – increase concentration or pH value
Stability	when necessary	refractometer	oiling	add concentrate, enquiries to supplier
Foam reaction	when necessary	shaking test	too much foam, foam disperses too slowly	avoid aeration, increase water hardness, ix with defoamer

* According to manufacturers' instructions

4.4.2. Chips disposal

Chips resulting from cutting operations must be disposed of in accordance with the relevant regulations.

- Let the chips drip excess fluid!
- Fill a watertight container with the chips! Be careful that the container does not leak, because even after a long dripping time, they still contain coolant residue.
- *Place the container into the care of a disposal company equipped for the disposal of chips contaminated with cooling liquid.* In case the machine is equipped with micro-spray installation, the chips must also be handed over to a disposal company.

4.5. Hydraulic, Greases and oils

4.5.1. Gearbox oils

In gearboxes, oil is used for the whole lifetime of the gearbox. We recommend replacing of the filling oil in case of repair.

Use oils with specification DIN 51517 in the gearboxes. Select the viscosity grade ISO VG according to the original oil fill.

Attention:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils must not be mixed!

Recommended oils and quantity according to the type of the band saw

Band saw	Gearbox oil	Capacity
Individual 520.360 GH	Shell Tivela S 320	3,3 l
Swarf conveyor	Shell Tivela S 320	0,075 l

Comparative table of the gearbox oils

Manufacturer	Viscosity grade		
	ISO VG 100	ISO VG 220	ISO VG 320
BP	Energol GR-XP 100	Energol GR-XP 220	Energol GR-XP 320
Castrol	Alpha SP 100 Alpha MW 100	Alpha SP 220 Alpha MW 220	
Elf	Reductelf SP 100	Reductelf SP 220 Reductelf Synthese 220	Reductelf SP 320
Esso	Spartan EP 100	Spartan EP 220	Spartan EP 320
Mobil	Mobilgear 627	Mobilgear SHC 220 Mobilgear 630	Mobilgear 632
ÖMV		PG 220	
Paramo	PP 7	Paramo CLP 220	Paramo CLP 320
Shell	Shell Omala 100	Shell Omala 220 Shell Tivela S 220	Shell Omala 320 Shell Tivela S 320
Total	Carter EP 100	Carter EP 220	Carter EP 320

4.5.2. Lubricant greases

We recommend using lithium based saponified grease, class NGLI-2 for lubrication. Different greases are mixable, if their oil bases and consistence type are identical.



Comparative table of the lubricant greases:

Manufacturer	Type of the lubricant grease
BP	Energrease LS - EP
DEA	Paragon EP1
Esso	FETT EGL 3144
	Beacon EP 1 Beacon EP 2
FINA	FINA LICAL M12
Klüber	Microlube GB0
	Staburags NBU8EP Isoflex Spezial
Optimol	Optimol Longtime PD 0, PD1, PD2

Manufacturer	Type of the lubricant grease
Shell Aseol AG	ASEOL Litea EP 806-077
Texaco	Multifak EP1

4.5.3. Lubrication

There are several placing on the machine, which are necessary to grease periodically. It secures the right function of the machine.

Lubrication place	Lubrication
	<p>The guiding cubes leading – grease with oil from both sides once a week.</p>
	<p>The linear guiding of the saw arm – lubricate with grease once a three months (see chapter Lubricant greases). Use 3-5g grease on the every carriage of the linear guiding. Use the grease gun to the lubrication. Drive 3-5 times whole line of the linear guiding during lubrication.</p>

4.5.4. Hydraulic oils

Replace the hydraulic oil once in 2 years, because the oil can deteriorate its properties and cause problems the hydraulic equipment. If the hydraulic system is equipped with filter (2SF 56/48-0,063), replace the filter too.

Use oils with specification DIN 51524-HLP, ISO 6743-4 and viscosity grade ISO VG 46 in hydraulic aggregates. Hydraulic oils quantity – see chapter **Hydraulic oil level check**.

Note:

When replacing, use oils recommended by BOMAR or oils, which has comparable parameters from the other manufacturers. Do not forget, that mineral and synthetic oils may not be mixed!

Comparative table of the hydraulic oils

Manufacturer	Type	Manufacturer	Type
Agip	Oso 46	Ina	Hidraol 46 HD
Aral	Vitam GF 46	Klüber	Lamora HLP 46
Avia	Avilub RSL 46	Hungary	Hidrokomol P 46
Benzina	OH-HM 46	Mobil	Mobil DTE 25
BP	Energol HLP 46	ÖMV	HLP 46
Bulgaria	MX-M/46	Poland	Hydrol 30
Castrol	Hyspin AWS 46	Rumania	H 46 EP
Čepro	Mogul HM 46	Russia	IGP 30
DEA	Astron HLP 4hy6	Shell	Tellus Oil 46

Manufacturer	Type	Manufacturer	Type
Elf	Elfolna 46	Sun	Sunvis 846 WR
Esso	Nuto H 46	Texaco	Rando HD B 46
Fam	HD 5040	Valvoline	Ultramax AW 46
Fina	Hydran 46		

4.5.5. Hydraulic unit service

After 50 hours working time, or the latest 3 month after the first run, the first service should be carried out. This includes:



- checking off all screws and connections, fixing points, tubes and hoses for leakage
- Check hydraulic oil level
- During time of duty the oil temperature shouldn't exceed 60-70°C
- check function of signaling components (thermometer, level gauge, dirty filter indicator)
- Check the adjustment of working pressure

To realise a high reliability of the power pack, the manufacturer lays down following inspection intervals

Interval	daily	weekly	monthly	three monthly	six monthly	annually
Hydraulic fluid						
Level	-	•	-	-	-	-
Temperature	-	•	-	-	-	-
Condition	-	-	•	-	-	-
Change interval	-	-	-	-	-	•
Filter						
Change interval	-	-	-	-	-	-
Other checks						
External Leakages	•	-	-	-	-	-
Contamination	•	-	-	-	-	-
Damages	•	•	-	-	-	-
Noise-(level)	•	-	-	-	-	-
Gauges	-	-	•	-	-	-

4.6. Machine cleaning

Clean the machine from the cooling liquid and impurities after every shift stopping. Conserve the guiding surfaces, mainly.

- Clamping jaws guiding of the vice.
- The guiding of the feeder.
- Loading surface of the vice.


4.7. Worn pieces replacement

4.7.1. Pushing bearing replacement


If it is impossible to adjust the bundle gripping assembly and the pushing bearing is worn, it needs to be replaced



1. Dismantle the saw band.
2. Disconnect the hose from the cooling agent eventually unmount microniser.
3. Unmount guiding cube from holder on saw.



4. Loosen the 2 clamp screws solid carbide guides and remove them..
5. Remove fixed hardmetal.




6. Remove retaining ring. Then unmount adjusting screw.



7. Remove other three screws.



8. Carefully remove the hardmetal. Remove disc springs.



9. Loosen the mounting worm (allen wrench no. 3). Remove the pivot with bearing from the guiding cube.



10. Insert the pivot to the vice.


Attention:

The vice has aluminium jaws, eventually, there has to be an aluminium agent to protect the pivot from damage.


11. Remove the bearing pivot from the bearing holder by means of the swager.



12. Remove the worn bearing and other damaged parts.
13. Fasten the holder to the vice.
14. Insert the bearing and washers and return the pivot to its original place.
15. Place the assembled piston guide cube. Piston must move freely in a guiding cube.
16. Worm screw defines the operation of the piston (piston has a slot in which is the worm). Tighten the worm, but with a minimum clearance to the piston could move.




17. Insert the disc springs. The number of disc springs must match the number of dismantled springs. Disc springs are folded against each other 1 to 1. Odd plate spring is near the harmetal carbide.




18. Insert the new hard metal guide. **Attention, Do not lose disc springs.** Ensure proper position of carbide guides – holes for 3 stop screws must be in the same position as the holes in a guiding cube.


19. Insert and tighten central screw.



20. Insert the retaining ring on central screw.
 21. Insert 3 stop screw around central screw.



22. Insert fixed hardmetal guiding and mount hard metal with two screws.




23. Using a short piece of the blade used on the machine, adjust the width of the gap between the guides. Loosen the central screw. Set the gap by central adjusting screw. Belt guides must walk freely without large and will also not scrub.

4.7.2. Saw band guiding pulleys replacement

If the saw band is not sufficiently guided by guiding pulleys or if the pulleys are obviously worn, the pulleys should be replaced.

Attention:
Guiding pulleys must be replaced together on both guiding cubes!



1. Release 2 screws. Dismantle the guiding cube of the saw band.

Attention:

*Mark both eccentrics placing and components on the eccentric!
 Eccentrics must not be replaced with each other!*



2. Tighten the guiding cube to the vice and dismantle both eccentrics with bearings following way.
3. Screw off nuts from eccentrics.
4. Remove eccentrics from bearings by means of the swager.



5. Change all bearings and other worn parts.
6. Install eccentrics to the cubes. Install components on both eccentrics in given order. Put bearings by means of the preparation on eccentrics.

Attention:

Do not replace the eccentrics placing in the cube.



7. Screw on nuts on both eccentrics and tighten them.



8. Insert the saw band to the guiding cube (cca 15 – 20 cm). Secure the movable hard metal guide with scotch so, that the saw band is pressed with guides and it is possible to move with saw band
9. Set the eccentrics by means of the wrenches, the saw band must run in the centre. Guide pulleys must not press too much on the band, but must spin freely during the band run

Optimal distance between the band and the pulley is 0,05 mm.

10. Tighten nuts on both eccentrics.
11. Remove the testing piece of saw band from the cube lead. Install the guiding cube on the machine.


4.7.3. Hard metal guides replacement

If the hard metal guides cannot be adjusted, they have to be replaced


ATTENTION!

Hard metal guides must be replaced together on both guiding cubes!!

1. Dismantle the saw band.
2. Disconnect the hose from the cooling agent eventually unmount microniser.
3. Unmount guiding cube from holder on saw.



4. Loosen the 2 clamp screws solid carbide guides and remove them..
5. Remove fixed hardmetal.



6. Remove retaining ring. Then unmount adjusting screw.




7. Remove other three screws..




8. Carefully remove the hardmetal. **Pozor, nesmí dojít ke ztrátě talířových pružin.**




9. The number of disc springs must match the number of dismantled springs. Disc springs are folded against each other 1 to 1 Odd plate spring is near the hardmetal carbide.




10. Insert the new hard metal guide. **Attention, Do not lose disc springs.** Ensure proper position of carbide guides – holes for 3 stop screws must be in the same position as the holes in a guiding cube.
11. Insert and tighten central screw.



12. Insert the retaining ring on central screw.
13. Insert three stop screw around central screw.



14. Insert fixed hardmetal guiding and mount hard metal with two screws.



15. Using a short piece of the blade used on the machine, adjust the width of the gap between the guides. Loosen the central screw. Set the gap by central adjusting screw. Belt guides must walk freely without large and will also not scrub.

4.7.4. Brush replacement

If the chip removing brush is not able to fulfil its function, it has to be replaced.

1. Hold shaft of the brush by wrench.



2. Release the nut on the brush, replace worn brush on the new brush, screw on the nut.
3. Set the brush to the saw band.

5. **Závady / Troubleshooting**

5.1. Mechanical problems

Problem	Possible causes	Repair
1. Slanting cut	- Wrongly adjusted hard metal guides.	Set according to the chapter „Servicing and adjustment“
	- Worn hard metal guides.	Replace to the chapter „Worn pieces replacement“
	- Wrongly adjusted cubes of the saw band guiding.	Set according to the chapter „Servicing and adjustment“
	- Worn bearings of the saw band guiding.	Replace according to the chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Set according to the chapter „Servicing and adjustment“
	- Worn swarf brush.	Replace according to the chapter „Worn pieces replacement“
	- Insufficient saw band stretching.	Rise the saw band stretching and set the limit switch.
	- Wrongly chosen tooth system of the saw band.	Replace the saw band and keep the instructions of manufacturer on new saw band choice.
	- Worn saw band.	Replace the saw band.
	- Wrongly balanced roller conveyor.	Set the roller conveyor.
	- Dirty feeding board.	Cleanse the feeding board from debris, chip and residue material.
	- Guiding arm and guiding cube are loosened.	Clamp the guiding arm.
	- Guiding arm and cube are too far from the material.	Set the guiding cube to the material.
	- Too fast cutting rate.	Lower the material feeding speed.
	- Unexpected oscillation in material quality.	Set the cut and feeding speed to the relevant material.
2. The cut is not cut upon desired angle	- Securing lever is loosened.	Check the securing lever efficiency and carry out its adjustment according to chapter „Servicing and adjustment“.
	- Set angle does not match the cut angle.	Check the angle adjustment with a protractor and possibly set it according to chapter „Servicing and adjustment“.
	- Insufficient saw band stretching.	Stretch the saw band and set the limit switch according to chapter „Servicing and adjustment“.
	- Guiding arm and guiding cube are loosened.	Fasten the guiding arm and the cube.
	- Dirt between material and clamping jaw.	Cleanse the material and mating jaw.
3. Short lifetime of the saw band	- Insufficient saw band stretching.	Raise the tightening of the saw band set the scanner of saw band tightening according to chapter „Servicing and adjustment“.
	- Worn swarf brush.	Check the swarf brush condition and replace it in case of excessive use as described in chapter „Worn pieces replacement“
	- Wrongly adjusted swarf brush.	Check swarf brush adjustment, set it according to chapter „Servicing and adjustment“
	- Over stretched saw band	Lower stretching of the saw band and set the limit switch of the saw band stretching according to chapter „Servicing and adjustment“
	- Wrongly adjusted hard metal guides.	Check the adjustment of the hard metal guides and carry out adjustment as described in chapter „Servicing and adjustment“
	- Worn hard metal guides of the saw band.	Check the condition of the hard metal guide and if it is too worn, replace hard metal guides according to chapter „Worn pieces replacement“

Problem	Possible causes	Repair
	- Worn saw band guide bearings.	Check guiding bearings and if you notice some sort of excessive damage, replace them according to chapter „Worn pieces replacement“
	- Wrongly adjusted guiding cubes of the saw band.	Set guiding cube according to chapter „Servicing and adjustment“
	- Wrongly adjusted down feed and saw band speed.	Adjust the feeding and speed of a saw band according to values published by saw band manufacturer.
	- Different material quality.	Adjust feeding and speed of a saw band according to desired material (try cut-test).
	- Low-class saw band	Replace the saw band (contact your local accessory supplier for more information)
	- Wrongly chosen saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly adjusted tracking.	Check the space between top of a saw band and driving wheel. Perhaps adjust the tracking as described in chapter „Servicing and adjustment“
4. Insufficient cut output.	- Worn saw band.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrong saw band tooth system.	Replace the saw band and keep instructions of the manufacturer on the choice.
	- Wrongly set down feed and speed of a saw band.	Set feed and speed of a saw band according to values published by saw band manufacturer.
5. The cut is not finished.	- Wrongly adjusted lower stop point of the saw frame.	Check lower limit switch and screw.
	- Stop point surface is messed-up.	Cleanse stop point surface of the limit switch from debris and residue material.
6. By choke is not possible turn	- Metal clamps between valve and panel.	Clamps must be removed and put on the shaft O-Ring about 10x2 mm.
	- Metal clams are in body of valve.	Valve must be cleared or changed.
7. Saw band drive cannot be started.	- Pressure switch is adjusted wrong.	Set the pressure switch according to chapter „Servicing and adjustment“
	- Pressure switch is defective.	Replace defective parts of the pressure switch.
8. The saw bands are cracked.	- In stretching wheel is wrong adjusting geometry.	Adjust distance band from recess wheel c.2 mm according to operating instructions.
	- Hard metal plates of circuit saw band are not adjusting.	Hard metal plates of circuit saw band must be adjusting according to operating instructions.
	- Guiding cubes are not adjusting (bearings + hard metal circuit)	Guiding cubes must be adjusting (bearings + hard metal circuit) according to operating instructions.
	- Bearings of guiding cubes are used (rolling elements are damaged or outside ring of bearing has conical form).	Bearings of guiding cubes must be replaced. Bearings must be adjusting according to operating instructions.
9. Damage tooth system of the saw band	- In gripping the lifting cylinder is backlash.	
	- Squeezed pin upper or downer holder of the lifting cylinder.	Exchange complete upper or downer holder of lifting cylinder.
10. The saw is cut downing.	- Geometry of hardmetal guiding cubes is wrong adjusted.	Hardmetal guiding cubes must be adjusted.
	- Bearings of guiding cubes are used.	Bearings of guiding cubes must be replaced.
11. Cleansing of the saw band is not functional.	- Elastic wheel of the brush drive is worn-down.	Elastic wheel of the brush must be changed.
	- Knurling of the driving wheel is worn-down.	Driving wheel must be changed.
	- The shaft of the brush drive is rusted.	The shaft of the brush must be cleaned and oiled.

Problem	Possible causes	Repair
	- The brush position and the brush cover is adjusted wrong – with the brush cannot be turned.	The brush cover must be posed, in order to the brush can be turned.
12. The saw arm periodically rise and fall during the cut; this cause short lifetime of the saw band.	- Backlash in driving wheel lodgement on the shaft.	Change the driving shaft for a long one, new bearings, distance ring, new driving wheel, spring, two covers on the forehead of the shaft + screws.
	- Worn channel for spring.	

5.2. Electric problems

Problem	Possible causes	Repair
1. Machine is not possible start.	- In socket is not voltage	Line voltage must be checked.
	- Transfer relay is closed (thermal protector)	Each FA relay must be checked.
	- Limit switch of saw band stretching, cover of frame or cover of saw band is not started.	Check of saw band stretching and covers closing.
2. When cut is finished, the frame is not raising.	- Bottom limit switch is adjusted wrong.	Bottom limit switch must be adjusted according to chapter ADJUSTING.
	- In hydraulic (pneumatic) ring is error. HYTOS (BOSCH) is not acting to frame uplift.	Function of magnetic valve must be checked, valve must be closed, voltage of clamps and inductor must be checked.
3. Electric motor and pump are without voltage. Between contactor and thermal protector is not voltage.	- Wrong contactor.	Replace contactor of engine.
4. The indicator of speed saw band is not functional.	- Sensor of speed is not adjusted.	Sensor of speed must be adjusted.
	- Defective display	The display must be changed.
	- Wrong sensor – diode of indicator speed is not light.	Sensor must be changed and adjusted.
5. Protector is switched off from engine hydraulic aggregate MA3 sometimes.	- Into hydraulic system is high working pressure.	Service engineer must reduce the pressure in hydraulic system.
6. The hydraulic aggregate cannot be started	Auxiliary contact on thermo-relay FA1 is defective.	Replace the defective contact on motor starter FA1.
7. Hydraulic aggregate is switched on but the saw arm or the main vice is not functional	- Wrong connection of electrical supply. The electrical phases are connected conversely.	The phases must be switched. Only service engineer can do this.
8. Cooling is not active	- Lack of cooling agent.	Fill the tank with cooling agent.
	- Thermal relay is defective	Change the thermal relay
	- Input hosepipe is broken or obstructed.	Check the cooling circuit and perhaps cleanse cooling system.
	- Cooling pump protection is defective	Check the protection of cooling pump if need change it.
	- Cooling pump is defective.	Replace the cooling pump.

5.3. Hydraulic problems

Problem	Possible causes	Repair
1. Hydrogenerator not supplying oil	• reverse rotation	Check the connections of each phase. Reconnect properly connection of the electrical phases.
	• shortage of oil in the tank	Add hydraulic oil
	• Oil viscosity does not correspond prescribed viscosity value	Change hydraulic oil.
	• Hydrogenerator malfunction	Call service
	• Wrong power supply connection.	Check the connections of each phase. Reconnect properly connection of the electrical phases.
2. Hydraulic oil contains bubbles	• Hydraulic circuit is not adequately deaerated	Make deaeration of hydraulic circuit.
	• Low oil level	Add hydraulic oil
	• the pump shaft seals damaged	Call service
3. Increased mechanical noise	• damaged joint drive	Call service
	• damaged or destroyed motor bearings	Call service
	• air intake	Check for leaks.
4. Low pressure, pump supplies oil	• problem in the safety valve	Wrong settings. Check the settings and adjust the safety valve.
	• pump wear	Call service
	• external or internal leakage	Call service
5. Hydrogenerator is seized	• damage by solid particles in oil	Make oil filtration, or call the service.
	• non-prescribed oil	Change hydraulic oil.
	• wrong type of oil	Change hydraulic oil.
	• exceeding the life of the pump	Call service
6. Overheating oil	• cooler malfunction	Check the cooler function or call service.
	• wear the pump, the energy is converted into heat	Call service
7. Hydraulic valve can not be readjusted	• electromagnet has no signal (voltage) - interrupted supply lines	Check again.
	• Electromagnet coil burnt	Replace coil – Call service.
	• spool valve sticking	Replace valve – Call service

6. **Schémata / Schemas / Schematics**

6.1. Elektrické schéma /
 Elektroschema /
 Wiring diagram 3x400 V, TN-C ,50Hz

<p>0 1 2 3 4 5 6 7 8 9</p>	 <p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p>	<p>Individual 520.360 (D)GH</p>	 <p>BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno</p> <p>Spol/Machine/Abstrich: Individual 520.360 (D)GH</p> <p>Název stránky/Name page/Name seiten: Úvodní strana/Start page/Startseite</p> <p>C.proj./Project/Projekt: ES-NG30-202/AG.1 Našeři/Power supply/Einspeisung: 3x400V/PE, 50Hz Datum/Date/Datum: 31.8.2012 Zpracoval/Processed/Hat. verarbeitet: HAL.FAR.</p> <p>Lib: 00 Lieč: 20</p>
----------------------------	---	---------------------------------	--

0	1	2	3	4	5	6	7	8	9
Obsah/ Table of contents/ Inhaltsverzeichnis									
Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum							
00	Úvodní strana/Start page/Startseite	31.8.2012							
01	Obsah/ Table of contents/ Inhaltsverzeichnis	21.9.2012							
02	I/O řídicí systém / I/O Control station / I/O Steuerung	2.9.2012							
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	27.9.2012							
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	31.8.2012							
04	Silová část M1/Power part M1/Feld partie M1	27.9.2012							
04.a	Silová část M2, M3/Power part M2, M3/Feld partie M2, M3	27.9.2012							
04.b	Silová část M4, M5/Power part M4, M5/Feld partie M4, M5	27.9.2012							
05	Deska zdroje/Power board/Netzgerat-Platte	12.9.2012							
06	Stykače motorů/Motor contactor/Motor-Schutzschalter	27.9.2012							
07	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
07.a	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
08	Vstupy/Inputs/Eingänge	30.8.2012							
09	Tlačítka ovládací panel/Button control panel/Taste Bedienpult	30.8.2012							
10	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	27.9.2012							
11	Řídicí systém/Control system/Steuersystem	7.9.2012							
12	Příslušenství/Accessories/Zubehör	12.9.2012							
13	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							
13.a	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							
13.b	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							

00



BOMAR, s.r.o.
 Těšební 1236/1
 CZ 627 00, Brno

Stroj/Machine/Maschine:

Individual 520.360 (D)GH

Název stránky/Name page/Name seite:

Obsah/ Table of contents/ Inhaltsverzeichnis

C.proj./Project/Projekt:

ES-NS30-202/AG.1

Název/Power supply/Energieangabe:

3x400V/PE, 50Hz

Datum/Date/Datum:

27.9.2012

Zpracoval/Processed/Has verarbeitet:

HALFAR

List:

01

List:

20

01




BOMAR, s.r.o.
Těžečná 1236/1
CZ 627 00, Brno

Stroj/Machine/Abstraktion:
Individual 520.360 (D)GH

Název strojku/Name page/Name station:
I/O řídící systém / I/O Control station / I/O Steuerung


C: /proj/Projekt/Projekt:
Název/Power supply/Einsparung: 3x400V+PE, 50Hz
Datum/Date/Datum: 2.9.2012
Zpracoval/Processed/Her: vav@brno.cz
HAI/PRA
Lib: ES-N339-20/2/6.1
02
L103
30

Individual 520.360 (D)GH




Pohled ze spodu/From under view/Blick nach


I/O	CZE	ENG	DE
IN 01	Svěrák upnut	Vice is clamped	Schraubstock ist gespannt
IN 02	Rameno dole	Arm is down	Rahmen ist unten
IN 03	Rameno nahoře	Arm is up	Rahmen ist oben
IN 04	Napnutí pásu	Blade tension	Bandspannung
IN 05	Motory OK	Motors OK	Motoren OK
IN 06	Bezpečnostní okruh uzavřen	Safety circle shut down	Sicherheitsschaltung gesperrt
IN 07	Tlačítko TOTAL STOP	Button TOTAL STOP	Taste TOTAL STOP
IN 08	Tlačítko START	Button START	Taste START
IN 09	Tlačítko STOP	Button STOP	Taste STOP
IN 10	MANUAL	MANUAL	MANUAL
IN 11	CYKLUS	CYCLE	ZYKLUS
IN 12	NC	NC	NC
IN 13	NC	NC	NC
IN 14	NC	NC	NC
IN 15	NC	NC	NC
IN 16	NC	NC	NC
IN 17	NC	NC	NC
IN 18	NC	NC	NC
IN 19	Tlačítko napnout pás	Button band tension	Taste band spannen
IN 20	Tlačítko povolit pás	Button band release	Taste band lösen
IN 21	Tlačítko rameno nahoru	Button arm up	Taste Rahmen nach oben
IN 22	NC	NC	NC
IN 23	Přítlak upnut	Upper vice is clamped	Ober Schraubstock ist gespannt
IN 24	NC	NC	NC
OUT 01+	Start FM1	Start FM1	Start FM1
OUT 01-			
OUT 02+	NC	NC	NC
OUT 02-			
OUT 03+	NC	NC	NC
OUT 03-			
OUT 04	Motor chlazení	Coolant pump	Motor Kühlung
OUT 05	Čerpadlo hydrauliky 1.rychlost	Hydraulic pump 1.speed	Hydraulikpumpe 1.Geschwindigkeit
OUT 06	Čerpadlo hydrauliky 2.rychlost	Hydraulic pump 2.speed	Hydraulikpumpe 2.Geschwindigkeit
OUT 07	Svěrák upnout	Vice clamp	Schraubstock spannen
OUT 08	Svěrák povolit	Release vice	Schraubstock lösen
OUT 09	Svěrák doleva	Vice to the left	Schraubstock nach links
OUT 10	Svěrák doprava	Vice to the right	Schraubstock nach rechts
OUT 11	Rameno nahoru	Arm up	Rahmen nach oben
OUT 12	Rameno dolů	Arm down	Rahmen nach unten
OUT 13	Rameno rychle	Arm fast	Rahmen schnell
OUT 14	Přítlak upnout	Upper vice clamp	Ober Schraubstock spannen
OUT 15	Přítlak povolit	Release upper vice	Ober Schraubstock lösen
OUT 16	Napnout pás	Sawblade tension	Spannen des Sägebandes
OUT 17	Uvolnit pás	Sawblade leave	Entspannen des Sägebandes
OUT 18	Mikronizer	Microniser	Mikronizer
OUT 19	Kontrolka start	Indicator start	Kontrolllicht start




02	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Názov súčiny/Name part/Name seller: Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	C.proj./Project/Projekt: ES NS30-202/G.1 Napájení/Power supply/Einspeisung: 3x400V+PE, 50Hz Datum/Date/Datum: 27.9.2012 Zpracoval/Processed/Hat. verarbeitet: HALFAR
	BOMAR, s.r.o., Těžební 1236/1 CZ 627 00, Brno		List: 03 Listů: 20




**Schemata
Schemata
Schematics**






Název strojky/Name part/Name seřazení: Silová část M2, M3/Power part M2, M3	C/Proj./Project/Projekt: ES/NS30-202/A6.1	LIB: 04.9
	Název/Power supply/Emiseung: 3x400V-PE, 50Hz	Datum/Date/Datum: 25.10.2012
Stroj/Machine/Abstrich: Individual 520.360 (D)GH	Zpracoval/Processed/Herst. ver.arbeitest: HAL/FAR.	

Schemata
Schemata
Schematics




04.a	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Název strojky/Name page/Name selbst: Slova část M4, M5/Power part M4, M5/Field partie M4, M5	C:proj./Project/Projekt: ES/NE30-202/A6.1
	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno		Lib: 04.b
			Návrh/Power supply/Empeung: 3x400V-PE, 50Hz
			Datum/Date/Datum: 25.10.2012
			Lib0: 20
			Zpracoval/Processed/In-ht. ver-arbeitet: HAL/FAR




04.b	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název stádky/Name page/Name sellen: Deska zdroje/Power board/Netzgerat-Platte	C:\proj\Projekt\Projekt: ES NS30-202\G.1 Napájení/Power supply/Einspeisung: 3x400V/HE, 50Hz Datum/Date/Datum: 12.9.2012 Zpracoval/Processed/Has verarbeitet: HALFAR	List: 05 Libř: .20
------	--	--	--	-----------------------------




BOMAR, s.r.o.
Teřebnř 1236/1
CZ 627 00, Brno





06	 BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název strojky/Name pojez/Name sellen: Hydraulické ventily/Hydraulic valve/Hydroventil	C.proj./Project/Projekt: ES-NS30-202/G.1 Napájení/Power supply/Energieangabe: 3x400V/HE, 50Hz Datum/Date/Datum: 25.10.2012 Zpracoval/Processed/Hat verarbeitet: HALFAR	List: 07 Listo: 20
----	--	--	--	---	-----------------------------

Schemata Schemata Schematics




07

BOMAR, s.r.o.
Teřební 1236/1
CZ 627 00, Brno

Stroj/Machine/Maschine:
Individual 520.360 (D)GH

Název strojky/Name part/Name selbst:
Hydraulické ventily/Hydraulic valve/Hydroventil

C:proj./Project/Projekt:	ES/NE30-202/AV.1
Název/Power supply/Erzeugung:	3x400V+PE, 50Hz
Datum/Date/Datum:	25.10.2012
Zpracoval/Processed/In-ht. v-arbeitet:	HALFAR
Lib.0:	
Lib.0:	.20




07.a	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název strojky/Name page/Name sellen: Vstup/Inputs/Eingänge	C.proj/Project/Projekt: ES-NS30-202/G.1 Napájení/Power supply/Energieung: 3x400V/HE, 50Hz Datum/Date/Datum: 25.10.2012 Zpracoval/Processed/Has verarbeit: HALFAR.	List: 08 Libř: 20
------	--	--	--	----------------------------



BOMAR, s.r.o.
Těžební 1236/1
CZ 627 00, Brno

- 101 Svěrák upnut (Tlakový spínač) / Vice is clamped (Pressure switch) / Schraubstock ist gespannt (Druckschalter)
- 102 Rameno dole / Arm is down / Rahmen ist unten
- 103 Rameno nahore / Arm is up / Rahmen ist oben
- 104 Napnutí pásu / Blade tension / Bandspannung
- 123 Přítlak upnut (Tlakový spínač) / Upper vice is clamped (Pressure switch) / Ober Schraubstock ist gespannt (Druckschalter)
- 1004 Motory M1, M2, M3 - OK / Motors M1, M2, M3 - OK / Motoren M1, M2, M3 - OK

Schemata Schematics




08

BOMAR, s.r.o.
Těšební 1236/1
CZ 627 00, Brno

Stroj/Machine/Maschine:
Individual 520.360 (D)GH


Název stránky/Name page/Name sheet:
Tlačítka ovládací panel/Button control panel/Taste Bedienpult

C:proj/Projekt/Projekt: ES/NE30-202/AV.1
Lib: NE30-202/AV.1
Název/Power supply/Erzeugung: 3x400V/PE, 50Hz
Datum/Date/Datum: 25.10.2012
Lib0: 09
Lib00: 00
Zpracoval/Processed/Her. verarbeit: H.A.L.F.A.R.
Lib01: 00




Název strojky/Name page/Name sellen: Bepečnostní okruh/Safety circle/Sicherheitsbereich	C:\proj\Project\Projekt: Napietí/Power supply/Empeitang: Datum/Date/Datum:	ES NS30-202/G.1 3x400V/HE, 50Hz 25.10.2012
	List: 10 Uklád: .20	
Stroj/Machine/Maschine: Individual 520.360 (D)GH	Zpracoval/Processed/Has. verarbeit: HALFAR.	
BOMAR, s.r.o. Těžební 1236/1 CZ 627 00, Brno		

Schemata Schemata Schematics



	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Abstrine: Individual 520.360 (D)GH	Název stránky/Name page/Name seller: Řídicí systém/Control system/Steuersystem	C:\proj\Project\Projekt: Název/Power supply/Engpassung: Datum/Date/Datum: Zpracoval/Processed/Has verarbeit: HALPAB	List: 3x400V/HE, 50Hz 11 7.9.2012 20
	10				



11	 BOMAR, s.r.o. Teřební 1236/1 CZ 627 00, Brno	Stroj/Machine/Abstrich: Individual 520.360 (D)GH	Název střídky/Name page/Name sellen: Přislušenství/Accessories/Zubehör	C:proj/Project/Projekt: ES:NG30-202/G:1	List: ES:NG30-202/G:1
		Datum/Date/Datum: 25.10.2012	Datum/Date/Datum: 25.10.2012	Název/Power supply/Energieang: 3x400V/HE, 50Hz	List: 12
				Zpracoval/Processed/Has: verarbeit: HALFAR	List: 12
					List: 20

Schemata Schemata Schematics

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-RCF1	RCF filter	FBOPRL624		91.041.015	1	/04.4			
-RCF2	RCF filter	FBOPRL624		91.041.015	1	/04.a.1			
-RCF3	RCF filter	FBOPRL624		91.041.015	1	/04.a.4			
-RCF11	RCF filter	FBOPRL624		91.041.015	1	/04.b.0			
-RCF12	RCF filter	FBOPRL624		91.041.015	1	/04.b.0			
-RP1	Potentiometer 5k	TP195 4x7/IN20A		91.283.015	1	/04.b.3			
=OP1-SB501	Emergency-stop mushroom push-button + 3xNC	YW1B-V4E02R		91.060.084	1	/10.2			
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/05.2			
-KM1	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/06.1			
-KM2	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.3			
-KM2	Mechanical interlock for contactors DILM12	F-MO DILM12-XMV	EATON	91.041.012	1	/06.3			
-KM3	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.4			
-KM3	Auxiliary contact of contactor - 2xNO	F-MO DILA-XH120	EATON	91.041.010	1	/06.4			
-KM11	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.6			
-KM12	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.7			
=OP1-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.a.8			
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/10.8			
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/09.1			
=OP1-SB1	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.1			
=OP1-SB2	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.2			
=OP1-SB2	Black switch head	M22-D-S	EATON	91.060.035	1	/09.2			
=OP1-SB3	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/09.3			
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/09.3			
=OP1-SB3	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.3			
=OP1-SB8	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/10.4			
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/10.4			
-TR2	Transformer 400V/230V, 0.13A, 30VA	JOC E2520-0022	ELEKTROKOV	91.080.027	1	/04.b.8			
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			

 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Název stránky/Name page/Name seiten: Kusovník artiklů/ Parts list/ Artikelstückliste		C:proj./Project/Projekt: ESNE30-202/A6.1
		Lišt: Název/Power supply/Erzeugung: Datum/Date/Datum: Zpracoval/Processed/Verarbeitet:	3x400V+PE, 50Hz 1.10.2012 HALFR.	Lišt: Lišt: Lišt:

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-FU2	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			
-FU3	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			
-FU4	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			
-FU5	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.0			
-FU6	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.1			
-FU7	Tube fuse - 6,3A/250V, slow, 5x20	T6.3A/250V	ESKA	91.230.002	1	/05.4			
-FU8	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/05.4			
-FU9	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/05.4			
-FU10	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/12.1			
-M1	Pump - 120W, 230/400V	4C0A4-12H	Emp	91.020.015	1	/04.6			
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/05.1			
-SQ21	Safety limit switch, 2xNC	QXS8	KEDU	91.173.012	1	/10.2			
-SQ22	Safety limit switch, 2xNC	QXS8	KEDU	91.173.012	1	/10.2			
-PA1	Fuse case for cylindrical fuse 10x38mm - 3P, size 10	OPV10/3	OEZ	91.241.002	1	/04.b.1			
-PA1	Cylindric fuse - 20A, 10x38, fast, gG characteristic	PV10 20A gG	OEZ	91.230.038	3	/04.b.1			
-SQ4	Limit switch - 1NC+1NO, M20, slow	D4N-4A31	OMRON	91.173.007	1	/08.4			
-SQ2	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.2			
-SQ3	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.3			
-FA1	Motor-overcurrent circuit breaker 0.25-0.4A	GZ1M03	SCHNEIDER	91.235.022	1	/04.6			
-FA1	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1AN11	SCHNEIDER	91.046.004	1	/04.6			
-FA2	Motor-overcurrent circuit breaker 1.6-2.5A	GZ1M07	SCHNEIDER	91.235.030	1	/04.a.2			
-FA2	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1AN11	SCHNEIDER	91.046.004	1	/04.a.2			
-QS1	Main switch 3P, 32A	VCF1-32A	SCHNEIDER	91.170.012	1	/04.0			
-BM1	Safety relay - 4xNO	SVA 4064K	WIELAND	91.051.026	1	/10.4			
-CU1	PRO-4.3	PRO-4.3	Bomar	265.917	1	/11.0			
-FM1	Frequency converter - 3kW, 3x400V	VACON010-3L-0008-4	VACON	91.012.061	1	/04.b.1			
-RET1	Multifunction time relay	CRM-93H/UNI	ELKO	91.051.031	1	/06.7			
-FU1	Fuse case	Wk4/THSIS...U	WIELAND	91.251.102	1	/04.b.8			

0	1	2	3	4	5	6	7	8	9																								
Parts list																																	
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page																											
-FU2	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/04.b.8																											
-FU3	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/04.b.8																											
-FU4	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/04.b.8																											
-FU5	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/05.0																											
-FU6	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/05.1																											
-FU7	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/05.4																											
-FU8	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/05.4																											
-FU9	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/05.4																											
-FU10	Fuse case	Wk4/TTHS5...J	WIELAND	91.251.102	1	/12.1																											
-M5	Cooling ventilator - 230V, 50Hz, 0.12A	RAH1278B1-C	XFAN	91.015.105	1	/04.b.8																											
13.a <table border="1" style="float: right; margin-top: 10px;"> <tr> <td colspan="2">C.proj./Project/Projekt:</td> <td>ESNE30-202/A6.1</td> </tr> <tr> <td colspan="2">Název/Power supply/Erzeugung:</td> <td>3x400V+PE, 50Hz</td> </tr> <tr> <td colspan="2">Datum/Date/Datum:</td> <td>27.9.2012</td> </tr> <tr> <td colspan="2">Zpracoval/Processed/Verarbeitet:</td> <td>HALFAR</td> </tr> <tr> <td>Lib:</td> <td>ESNE30-202/A6.1</td> <td></td> </tr> <tr> <td>Lib.b</td> <td>3x400V+PE, 50Hz</td> <td></td> </tr> <tr> <td>Lib.0:</td> <td>27.9.2012</td> <td></td> </tr> <tr> <td>Lib.0:</td> <td>HALFAR</td> <td></td> </tr> </table>										C.proj./Project/Projekt:		ESNE30-202/A6.1	Název/Power supply/Erzeugung:		3x400V+PE, 50Hz	Datum/Date/Datum:		27.9.2012	Zpracoval/Processed/Verarbeitet:		HALFAR	Lib:	ESNE30-202/A6.1		Lib.b	3x400V+PE, 50Hz		Lib.0:	27.9.2012		Lib.0:	HALFAR	
C.proj./Project/Projekt:		ESNE30-202/A6.1																															
Název/Power supply/Erzeugung:		3x400V+PE, 50Hz																															
Datum/Date/Datum:		27.9.2012																															
Zpracoval/Processed/Verarbeitet:		HALFAR																															
Lib:	ESNE30-202/A6.1																																
Lib.b	3x400V+PE, 50Hz																																
Lib.0:	27.9.2012																																
Lib.0:	HALFAR																																

6.2. Elektrické schéma /
 Elektroschema /
 Wiring diagram 3x400 V, TN-C-S ,50Hz

<p>0 1 2 3 4 5 6 7 8 9</p>	 <p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p>	<p>Individual 520.360 (D)GH</p>	<p>Společnost/Abstrakt: Individual 520.360 (D)GH</p>	<p>Název stránky/Name page/Name seiten: Úvodní strana/Start page/Startseite</p>	<p>C.proj./Project/Projekt: ESNG30-201/AG.1 Našeji/Power supply/Einspeisung: 3x400V/PE+HN, 50Hz Datum/Date/Datum: 18.12.2012 Zpracoval/Processed/Has. verarbeitet: HAL.FAR.</p>	<p>Lib: 00 List: 00 Lič: 00</p>
----------------------------	---	---------------------------------	--	--	--	---

0	1	2	3	4	5	6	7	8	9
Obsah/ Table of contents/ Inhaltsverzeichnis									
Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum							
00	Úvodní strana/Start page/Startseite	31.8.2012							
01	Obsah/ Table of contents/ Inhaltsverzeichnis	12.9.2012							
02	I/O řídicí systém / I/O Control station / I/O Steuerung	2.9.2012							
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	27.9.2012							
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	31.8.2012							
04	Silová část M1/Power part M1/Feld partie M1	12.9.2012							
04.a	Silová část M2, M3/Power part M2, M3/Feld partie M2, M3	4.9.2012							
04.b	Silová část M4, M5/Power part M4, M5/Feld partie M4, M5	12.9.2012							
05	Deska zdroje/Power board/Netzgerat-Platte	12.9.2012							
06	Stykače motorů/Motor contactor/Motor-Schutzschalter	27.9.2012							
07	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
07.a	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
08	Vstupy/Inputs/Eingänge	30.8.2012							
09	Tlačítka ovládací panel/Button control panel/Faste Bedienpult	30.8.2012							
10	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	3.9.2012							
11	Řídicí systém/Control system/Steuer system	13.9.2012							
12	Příslušenství/Accessories/Zubehör	11.9.2012							
13	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							
13.a	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							
13.b	Kusovník artiklů/ Parts list/ Artikelstückliste	27.9.2012							

00



BOMAR, s.r.o.
 Těšební 1236/1
 CZ 627 00, Brno

Stroj/Machine/Maschine:

Individual 520.360 (D)GH

Název stránky/Name page/Name seite:

Obsah/ Table of contents/ Inhaltsverzeichnis

C.proj./Project/Projekt:

ESNE302/AG.1

Libř:

01

Název/Power supply/Empeung:

3x400V+PE+N, 50Hz

Libř0:

01

Datum/Date/Datum:

18.12.2012

Libř0:


01

Zpracoval/Processed/Herarbeitet:

HALFR.

Libř0:

20




BOMAR, s.r.o.
Třebeň 1236/1
CZ 627 00, Brno

Individual 520.360 (D)GH

10

Stroj/Machine/Maschine
Individual 520.360 (D)GH



0
1
2
3
4
5
6
7
8
9

Pohled ze spodu/From under view/Blick nach

I/O	CZE	ENG	DE
IN 01	Svěrák upnut	Vice is clamped	Schraubstock ist gespannt
IN 02	Rameno dole	Arm is down	Rahmen ist unten
IN 03	Rameno nahoře	Arm is up	Rahmen ist oben
IN 04	Napnutí pásu	Blade tension	Bandspannung
IN 05	Motory OK	Motors OK	Motoren OK
IN 06	Bezpečnostní okruh uzavřen	Safety circle shut down	Sicherheitsschaltung gesperrt
IN 07	Tlačítko TOTAL STOP	Button TOTAL STOP	Taste TOTAL STOP
IN 08	Tlačítko START	Button START	Taste START
IN 09	Tlačítko STOP	Button STOP	Taste STOP
IN 10	MANUAL	MANUAL	MANUAL
IN 11	CYKLUS	CYCLE	ZYKLUS
IN 12	NC	NC	NC
IN 13	NC	NC	NC
IN 14	NC	NC	NC
IN 15	NC	NC	NC
IN 16	NC	NC	NC
IN 17	NC	NC	NC
IN 18	NC	NC	NC
IN 19	Tlačítko napnout pás	Button band tension	Taste band spannen
IN 20	Tlačítko povolit pás	Button band release	Taste band lösen
IN 21	Tlačítko rameno nahoru	Button arm up	Taste Rahmen nach oben
IN 22	NC	NC	NC
IN 23	Přítlak upnut	Upper vice is clamped	Ober Schraubstock ist gespannt
IN 24	NC	NC	NC
OUT 01+	Start FM1	Start FM1	Start FM1
OUT 01-			
OUT 02+	NC	NC	NC
OUT 02-			
OUT 03+	NC	NC	NC
OUT 03-			
OUT 04	Motor chlazení	Coolant pump	Motor Kühlung
OUT 05	Čerpadlo hydrauliky 1.rychlost	Hydraulic pump 1.speed	Hydraulikpumpe 1.Geschwindigkeit
OUT 06	Čerpadlo hydrauliky 2.rychlost	Hydraulic pump 2.speed	Hydraulikpumpe 2.Geschwindigkeit
OUT 07	Svěrák upnout	Vice clamp	Schraubstock spannen
OUT 08	Svěrák povolit	Release vice	Schraubstock lösen
OUT 09	Svěrák doleva	Vice to the left	Schraubstock nach links
OUT 10	Svěrák doprava	Vice to the right	Schraubstock nach rechts
OUT 11	Rameno nahoru	Arm up	Rahmen nach oben
OUT 12	Rameno dolů	Arm down	Rahmen nach unten
OUT 13	Rameno rychle	Arm fast	Rahmen schnell
OUT 14	Přítlak upnout	Upper vice clamp	Ober Schraubstock spannen
OUT 15	Přítlak povolit	Release upper vice	Ober Schraubstock lösen
OUT 16	Napnout pás	Sawblade tension	Spannen des Sägebandes
OUT 17	Uvolnit pás	Sawblade leave	Entspannen des Sägebandes
OUT 18	Mikronizer	Microniser	Mikronizer
OUT 19	Kontrolka start	Indicator start	Kontrollicht start

Název stroje/Name machine
I/O field system / I/O control station / I/O Steuerung

11

11

C:proj/Projekt/Projekt:
Název/Name supply/Einsparung:
Datum/Date/Datum:
Zpracoval/Processed/Ver. vstřelitel:
HJL/PRL

11

11

ES: N330-201/6.1
18.12.2012
HJL/PRL


11

11

Lib:
3x430V/PE/NE/50Hz/02
1100

11

11



02

BOMAR, s.r.o.
Těžební 1236/1
CZ 627 00, Brno




Stroj/Machine/Abstrich:
Individual 520.360 (D)GH


Název stránky/Name page/Name section:
Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure
RS1/ Platzierung der Elemente im Schaltschrank RS1

C.proj./Project/Projekt:
ES: NS30-2011/G.1
Název/Power supply/Engelung:
3x400V/PE+N, 50Hz
Datum/Date/Datum:
18.12.2012
Zpracoval/Processed/Has. verarbeitet:
HALFAR

Lišt:
3x400V/PE+N, 50Hz
Lišt:
18.12.2012
Lišt:
HALFAR
Lišt:
.20



03




C:proj./Project/Projekt:	ESN30201/A6.1	Lib:	
Nazdeni/Power supply/Emisung:	3x400V-PE-N, 50Hz	Lib:04	
Datum/Date/Datum:	18.12.2012	Lib:01	
Zpracoval/Processed/Verarbeitet:	HALFAR	Lib:00	


Název strojky/Name pump/Name selbst:
Slova část M1/Power part M1/Feld partie M1


Stroj/Machine/Maschine:
Individual 520.360 (D)GH

BOMAR, s.r.o.
Těžební 1236/1
CZ 627 00, Brno




BOMAR, s.r.o., Těšební 1236/1, CZ 627 00, Brno	Název strojky/Name page/Name sellen: Silová část M2, M3/Power part M2, M3	C.proj./Project/Projekt: Název/Power supply/Energieart: Datum/Date/Datum:	ES NS30-201/AG.1 3x400V/RE+N, 50Hz 18.12.2012
		Zpracoval/Processed/Has. verarbeitet:	HALFAR.






04.b	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název stádky/Name page/Name sellen: Deska zdroje/Power board/Netzgerat-Platte	C:\proj\Projekt\Projekt: ES NS90-201\AG.1	Lišt: ES
	BOMAR, s.r.o., Teřební 1236/1 CZ 627 00, Brno		Napájení/Power supply/Einspeisung: 3x400V/RE+N, 50Hz	Lišt: 05
			Datum/Date/Datum: 18.12.2012	Lišt: .20
			Zpracoval/Processed/Has verarbeitet: HALFAR	

Schemata Schemata Schematics






06	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název strojky/Name page/Name sellen: Hydraulické ventily/Hydraulic valve/Hydroventil	C:\proj\Project\Projekt: ES:NG30-201\AG.1 Název/Power supply/Energieartung: 3x400V+PE+N, 50Hz Datum/Date/Datum: 18.12.2012 Zpracoval/Processed/Has. verarbeitet: HALFAR	Lišt: 3x400V+PE+N, 50Hz Libř0: 18.12.2012 Libř0: .20
----	--	---	--	---




BOMAR, s.r.o.,
Teřebň 1236/1
CZ 627 00, Brno

Schemata Schemata Schematics



07


BOMAR, s.r.o. Teřebn 1236/1 CZ 627 00, Brno	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název stávk/Name page/Name seller: Hydraulické ventily/Hydraulic valve/Hydroventil	C.proj/Project/Projekt:	ES:NS30-201/VG.1
			Napájení/Power supply/Einspeisung:	3x400V/RE-NN, 50-Hz
			Datum/Date/Datum:	18.12.2012
			Libč:	HALFAR
			Zpracoval/Processed/Has. verarbeitet:	
			Libč:	20




07.a	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název strojky/Name page/Name sellen: Vstup/Inputs/Eingänge	C:\proj\Project\Projekt: ES-NS30-2011\AG.1 Název/Power supply/Energiepunkt: 3x400V/HE+N, 50Hz Datum/Date/Datum: 18.12.2012 Zpracoval/Processed/Has verarbeitet: HALFAR	List: K8 L8 L8K0: .20
------	--	--	---	-----------------------------------

- 101 Světlák upnut (Tlakový spínač) / Vice is clamped (Pressure switch) / Schraubstock ist gespannt (Druckschalter)
- 102 Rameno dole / Arm is down / Rahmen ist unten
- 103 Rameno nahoře / Arm is up / Rahmen ist oben
- 104 Napnutí pásu / Blade tension / Bandspannung
- 123 Přítlak upnut (Tlakový spínač) / Upper vice is clamped (Pressure switch) / Ober Schraubstock ist gespannt (Druckschalter)
- 1004 Motory M1, M2, M3 - OK / Motors M1, M2, M3 - OK / Motoren M1, M2, M3 - OK


Schemata Schematics








09	Stroj/Machine/Abstricht: Individual 520.360 (D)GH	Název schémky/Name page/Name sheet: Bezpečnostní okruh/Safety circle/Sicherheitsbereich	ES-NS30-201/A6.1	Lib: 10
			Projekt/Project: Napájení/Power supply/Emengeung: 3x400V+PE+N, 50Hz	Lib: 10
			Datum/Date/Datum: 18.12.2012	Lib: 0
			Zpracoval/Processed/In-ht. ver.arbeitet: HAL/FAR	Lib: 20

Schemata
Schemata
Schematics



	BOMAR, s.r.o., Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Název stránky/Name page/Name seller: Řídicí systém/Control system/Steuersystem	C:\proj\Project\Projekt: Název/Power supply/Engpassung: Datum/Date/Datum: Zpracoval/Processed/Has verarbeitet:	List: 3x400V/HEIN, 90Hz 11 18.12.2012 Liskó: HALPÁR:
					10 20



11	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název střežky/Name page/Name sellen: Přislúšenství/Accessories/Zubehör		C:proj/Project/Projekt: ES:NG30-2011/G.1	List: ES:NG30-2011/G.1
		BOMAR, s.r.o., Teřební 1236/1 CZ 627 00, Brno		Název/Power supply/Energieang: 3x400V/RE+LN, 50Hz	
				Datum/Date/Datum: 18.12.2012	
				Liskó: HALFAR	
				Zpracoval/Processed/Has. verarbeitet: HALFAR	
				Liskó: .20	

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-RCF1	RCF filter	FBOPRL624		91.041.015	1	/04.4			
-RCF2	RCF filter	FBOPRL624		91.041.015	1	/04.a.1			
-RCF3	RCF filter	FBOPRL624		91.041.015	1	/04.a.4			
-RCF11	RCF filter	FBOPRL624		91.041.015	1	/04.b.0			
-RCF12	RCF filter	FBOPRL624		91.041.015	1	/04.b.0			
-RP1	Potentiometer 5k	TP195 4x7/M20A		91.283.015	1	/04.b.3			
=OP1-SB501	Emergency-stop mushroom push-button + 3MOC	YW1B-V4E02R		91.060.084	1	/10.2			
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03	Bomar	265.915	1	/05.2			
-KM1	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/06.1			
-KM2	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.3			
-KM2	Mechanical interlock for contactors DILM12	F-MO DILM12-XMV	EATON	91.041.012	1	/06.3			
-KM3	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.4			
-KM3	Auxiliary contact of contactor - 2xNO	F-MO DILA-XH120	EATON	91.041.010	1	/06.4			
-KM11	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.6			
-KM12	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.7			
=OP1-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.a.8			
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/10.8			
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/09.1			
=OP1-SB1	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.1			
=OP1-SB2	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.2			
=OP1-SB2	Black switch head	M22-D-S	EATON	91.060.035	1	/09.2			
=OP1-SB3	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/09.3			
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/09.3			
=OP1-SB3	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.3			
=OP1-SB8	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/10.4			
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/10.4			
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			
-FU2	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.0			

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-FU3	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.1			
-FU4	Tube fuse - 6,3A/250V, slow, 5x20	T6.3A/250V	ESKA	91.230.002	1	/05.4			
-FU5	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/05.4			
-FU6	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/05.4			
-FU8	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/12.1			
-M1	Pump - 120W, 230/400V	4C0A4-12H	Emp	91.020.015	1	/04.6			
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.38A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/05.1			
-SQ21	Safety limit switch, 2xNC	QXS8	KEDU	91.173.012	1	/10.2			
-SQ22	Safety limit switch, 2xNC	QXS8	KEDU	91.173.012	1	/10.2			
-PA1	Fuse case for cylindrical fuse 10x38mm - 3P, size 10	OPV10/3	OEZ	91.241.002	1	/04.b.1			
-PA1	Cylindric fuse - 20A, 10x38, fast, gG characteristic	PV10 20A gG	OEZ	91.230.038	3	/04.b.1			
-SQ4	Limit switch - 1NC+1NO, M20, slow	D4N-4A31	OMRON	91.173.007	1	/08.4			
-SQ2	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.2			
-SQ3	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.3			
-FA1	Motor-overcurrent circuit breaker 0.25-0.4A	GZ1M03	SCHNEIDER	91.235.022	1	/04.6			
-FA1	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1AN11	SCHNEIDER	91.046.004	1	/04.6			
-FA2	Motor-overcurrent circuit breaker 1.6-2.5A	GZ1M07	SCHNEIDER	91.235.030	1	/04.a.2			
-FA2	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1AN11	SCHNEIDER	91.046.004	1	/04.a.2			
-QS1	Main switch 3P, 32A	VCF1-32A	SCHNEIDER	91.170.012	1	/04.0			
-BM1	Safety relay - 4xNO	SVA 4064K	WIELAND	91.051.026	1	/10.4			
-CU1	PRO-4.3	PRO-4.3	Bomar	265.917	1	/11.0			
-FM1	Frequency converter - 3kW, 3x400V	VACON0010-3L-0008-4	VACON	91.012.061	1	/04.b.1			
-RET1	Multifunction time relay - 12-240V, 10 functions	CRM-91H/UNI	ELKO	91.051.027	1	/06.7			
-FU1	Fuse case	WK4/THSIS...U	WIELAND	91.251.102	1	/04.b.8			
-FU2	Fuse case	WK4/THSIS...U	WIELAND	91.251.102	1	/05.0			
-FU3	Fuse case	WK4/THSIS...U	WIELAND	91.251.102	1	/05.1			
-FU4	Fuse case	WK4/THSIS...U	WIELAND	91.251.102	1	/05.4			
-FU5	Fuse case	WK4/THSIS...U	WIELAND	91.251.102	1	/05.4			



BOMAR, s.r.o.
Teřebn 1236/1
CZ 627 00, Brno


Stroj/Machine/Maschine:
Individual 520.360 (D)GH

Název stránky/Name page/Name sellen:
Kusovník artiklů/ Parts list/ Artikelstückliste

C.proj./Project/Projekt:
Název/Power supply/Engesung:
Datum/Date/Datum:
Zpracoval/Processed/Has verarbeitet:


ES-NS30-201/AG.1
3x400V/HE+N, 50Hz
18.12.2012
HALFAR

Libř:
Libř:
Libř:
Libř:

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-FU6	Fuse case	WK4/7HSIS...J	WIELAND	91.251.102	1	/05.4			
-FU8	Fuse case	WK4/7HSIS...J	WIELAND	91.251.102	1	/12.1			
-M5	Cooling ventilator - 230V, 50Hz, 0.12A	RAH1278B1-C	XFAN	91.015.105	1	/04.b.8			
<div style="display: flex; justify-content: space-between; align-items: flex-end; margin-top: 20px;"> <div style="width: 30%;">  <p>BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno</p> </div> <div style="width: 40%; text-align: center;"> <p>Stroj/Machine/Machine: Individual 520.360 (D)GH</p> </div> <div style="width: 25%; text-align: right;"> <p>Název stránky/Name page/Name seller: Kusovník artiklů/ Parts list/ Artikelstückliste</p> </div> </div>									
							C.proj./Project/Projekt: ES NS30-201/VG.1 Nastavení/Power supply/Eingestaltung: 3x400V+PE+N, 50Hz Datum/Date/Datum: 18.12.2012 Zpracoval/Processed/Has verarbeitet: HALFAR		
							List: ES NS30-201/VG.1 Listb: 3x400V+PE+N, 50Hz Listc: 18.12.2012 Listd: HALFAR Liste: 20		


6.3. Elektrické schéma /
 Elektroschema /
 Wiring diagram 3x230 V, TN-C ,50Hz

<p>0 1 2 3 4 5 6 7 8 9</p>	 <p>Bomar, spol. s r.o. Těžební 1236/1 627 00 Brno Czech republic</p>	<p>Individual 520.360 (D)GH</p>	<p>Společnost/Mechanism: Individual 520.360 (D)GH</p>	<p>Číslo stránky/Name page/Name sheet: Úvodní strana/Start page/Startseite</p>	<p>C.proj./Project/Projekt: ES-NG30-203/AG.1 LIB: 00 Napájení/Power supply/Einspeisung: 3x230V/PE, 50Hz Datum/Date/Datum: 22.1.2013 Zpracoval/Processed/Has. verarbeitet: HAL.FAR. Ver. 00</p>
----------------------------	---	---------------------------------	--	---	---

0	1	2	3	4	5	6	7	8	9
Obsah/ Table of contents/ Inhaltsverzeichnis									
Stránka/Page/Seite	Název stránky/Name page/Name Seite	Datum/Date/Datum							
00	Úvodní strana/Start page/Startseite	31.8.2012							
01	Obsah/ Table of contents/ Inhaltsverzeichnis	16.10.2012							
02	I/O řídicí systém / I/O Control station / I/O Steuerung	2.9.2012							
03	Rozmístění prvků v rozvaděči RS1/ Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1	24.10.2012							
03a	Ovládací panel OP1/Control panel OP1/Bedienpult OP1	31.8.2012							
04	Silová část M1/Power part M1/Feld partie M1	15.10.2012							
04.a	Silová část M2, M3/Power part M2, M3/Feld partie M2, M3	15.10.2012							
04.b	Silová část M4, M5/Power part M4, M5/Feld partie M4, M5	24.10.2012							
05	Deska zdroje/Power board/Netzgerat-Platte	27.9.2012							
06	Stykače motorů/Motor contactor/Motor-Schutzschalter	24.10.2012							
07	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
07.a	Hydraulické ventily/Hydraulic valve/Hydroventil	31.8.2012							
08	Vstupy/Inputs/Eingänge	27.9.2012							
09	Tlačítka ovládací panel/Button control panel/Faste Bedienpult	30.8.2012							
10	Bezpečnostní okruh/Safety circle/Sicherheitsbereich	27.9.2012							
11	Řídicí systém/Control system/Steueresystem	31.8.2012							
12	Příslušenství/Accessories/Zubehör	24.9.2012							
00	 BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Název stránky/Name page/Name seite: Obsah/ Table of contents/ Inhaltsverzeichnis	C.proj./Project/Projekt: ESNE30203/M6.1 Napiení/Power supply/Empeesung: 3x230V+PE, 50Hz Datum/Date/Datum: 22.1.2013 Zpracoval/Processed/Herarbeitet: HALFR.	List: 01 List: 01 List: 20				


01

Individual 520.360 (D)GH




Pohled ze spodu/From under view/Blick nach

I/O	CZE	ENG	DE
IN 01	Svěrák upnut	Vice is clamped	Schraubstock ist gespannt
IN 02	Rameno dole	Arm is down	Rahmen ist unten
IN 03	Rameno nahoře	Arm is up	Rahmen ist oben
IN 04	Napnutí pásu	Blade tension	Bandspannung
IN 05	Motory OK	Motors OK	Motoren OK
IN 06	Bezpečnostní okruh uzavřen	Safety circle shut down	Sicherheitsschaltung gesperrt
IN 07	Tlačítko TOTAL STOP	Button TOTAL STOP	Taste TOTAL STOP
IN 08	Tlačítko START	Button START	Taste START
IN 09	Tlačítko STOP	Button STOP	Taste STOP
IN 10	MANUAL	MANUAL	MANUAL
IN 11	CYKLUS	CYCLE	ZYKLUS
IN 12	NC	NC	NC
IN 13	NC	NC	NC
IN 14	NC	NC	NC
IN 15	NC	NC	NC
IN 16	NC	NC	NC
IN 17	NC	NC	NC
IN 18	NC	NC	NC
IN 19	Tlačítko napnout pás	Button band tension	Taste band spannen
IN 20	Tlačítko povolit pás	Button band release	Taste band lösen
IN 21	Tlačítko rameno nahoru	Button arm up	Taste Rahmen nach oben
IN 22	NC	NC	NC
IN 23	Přítlak upnut	Upper vice is clamped	Ober Schraubstock ist gespannt
IN 24	NC	NC	NC
OUT 01+	Start FM1	Start FM1	Start FM1
OUT 01-			
OUT 02+	NC	NC	NC
OUT 02-			
OUT 03+	NC	NC	NC
OUT 03-			
OUT 04	Motor chlazení	Coolant pump	Motor Kühlung
OUT 05	Čerpadlo hydrauliky 1.rychlost	Hydraulic pump 1.speed	Hydraulikpumpe 1.Geschwindigkeit
OUT 06	Čerpadlo hydrauliky 2.rychlost	Hydraulic pump 2.speed	Hydraulikpumpe 2.Geschwindigkeit
OUT 07	Svěrák upnut	Vice clamp	Schraubstock spannen
OUT 08	Svěrák povolit	Release vice	Schraubstock lösen
OUT 09	Svěrák doleva	Vice to the left	Schraubstock nach links
OUT 10	Svěrák doprava	Vice to the right	Schraubstock nach rechts
OUT 11	Rameno nahoru	Arm up	Rahmen nach oben
OUT 12	Rameno dolů	Arm down	Rahmen nach unten
OUT 13	Rameno rychle	Arm fast	Rahmen schnell
OUT 14	Přítlak upnout	Upper vice clamp	Ober Schraubstock spannen
OUT 15	Přítlak povolit	Release upper vice	Ober Schraubstock lösen
OUT 16	Napnout pás	Sawblade tension	Spannen des Sägebandes
OUT 17	Uvolnit pás	Sawblade leave	Entspannen des Sägebandes
OUT 18	Mikronizer	Microniser	Mikronizer
OUT 19	Kontrolka start	Indicator start	Kontrollicht start




02


	<p>BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno</p>	<p>Stroj/Machine/Maschine: Individual 520.360 (D)GH</p>	<p>Název souboru/Name page/Name selbst: Rozmístění prvků v rozvaděči RS1 / Placement of elements in enclosure RS1/ Platzierung der Elemente im Schaltschrank RS1</p>	<p>C:\proj\Project\Projekt: ESNE30-203\MS.1 Název/Power supply/Erzeugung: 3x230V+PE, 50Hz Datum/Date/Datum: 12.1.2013 Zpracoval/Processed/Her: w.arbatov: HAL/FAR</p>
---	---	--	--	---



03		BOMAR, s.r.o., Těšební 1236/1 CZ 627 00, Brno	Spoj/Mechy/Alschke: Individual 520.360 (D)GH	Název střešky/Name plate/Name seiten: Ovládací panel OP1/Control panel OP1/Bedienpult OP1	C.proj./Project/Projekt: ES-NS30-203/VG.1	Napájení/Power supply/Einspeisung: 3x230V/HE, 50Hz	Datum/Datý/Datum: 22.1.2013	List: 089	Zpracováno/Processed/Has. verarbeitet: H.M.F.A.R.	List: 089 List: 20
----	--	---	--	--	--	---	--------------------------------	--------------	--	-----------------------------

**Schemata
Schemata
Schematics**







04	Stroj/Machine/Abstricht:	Individual 520.360 (D)GH	Název strojky/Name part/Name selbst:	Silová část M2, M3/Power part M2, M3	Proj./Project/Projekt:	ES/NS30-203/M3.1	Lib:	04.a
	BOMAR, s.r.o., Těšební 1236/1 CZ 627 00, Brno				Návrh/Power supply/Emassung:	3x230V/PE, 50Hz	Lib0:	04.a
					Datum/Date/Datum:	22.1.2013	Lib0:	20
					Zpracoval/Processed/Her. ver.arbeitet:	HALFAR.		

0.48/0.6kW, D/Y, 3x230V, 3.82/4.8A, 1300/2810rpm, cos 0.84/0.85
 Čerpadlo hydrauliky 1. rychlost
 Hydraulic pump 1. speed
 Hydraulikpumpe 1. Geschwindigkeit

Čerpadlo hydrauliky 2. rychlost
 Hydraulic pump 2. speed
 Hydraulikpumpe 2. Geschwindigkeit





04.a	Stroj/Machine/Maschine: Individual 520.360 (D)GH	Název strojky/Name page/Name sellen: Silová část M4, M5/Power part M4, M5	C.proj./Project/Projekt: ES/NS30-203/AG.1
	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno		Lišt.: 04.b
			Název/Power supply/Engelung: 3x230V/PE, 50Hz
			Datum/Date/Datum: 22.1.2013
			Lišt.0: 20
			Zpracoval/Processed/Has verarbeit: HALFAR



04.b	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název stádky/Name page/Name sellen: Deska zdroje/Power board/Netzgerat-Platte	C:\proj\Projekt\Projekt: Nápnění/Power supply/Einspeisung: Datum/Date/Datum: Zpracoval/Processed/Has verarbeitet:	ES NS30-203/G.1 3x230V/HE, 50Hz 22.1.2013 HALFAR	List: 05 Libř: 20
------	--	---	--	---	----------------------------


**Schemata
Schemata
Schematics**






06	 BOMAR, s.r.o. Tešební 1236/1 CZ 627 00, Brno	Stroj/Machine/Abstrich: Individual 520.360 (D)GH	Název strojky/Name page/Name sellen: Hydraulické ventily/Hydraulic valve/Hydroventil	C:proj/Project/Projekt: ES:NGS-2023/G.1	List: 07
				Datum/Date/Datum: 22.1.2013	Libř: 20

Schemata Schemata Schematics





07.a	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název strojky/Name pump/Name seřazen: Vstupy/Inputs/Eingänge	C:proj./Project/Projekt: ES/NE30-203/M6.1	Libř: 08
	BOMAR, s.r.o., Třezbání 1236/1, CZ 627 00, Brno		Název/Power supply/Erzeugung: 3x230V+PE, 50Hz	Libř0:
			Datum/Date/Datum: 12.1.2013	Libř0:
			Zpracoval/Processed/In-til. ver.arbeitet: HALFAR.	Libř0: 20

Svěrák upnut
 (Tlakový spínač)
 Vice is clamped
 (Pressure switch)
 Schraubstock ist gespannt
 (Druckschalter)


Rameno nahore
 Arm is up
 Rahmen ist oben


Rameno dole
 Arm is down
 Rahmen ist unten

Napnutí pásu
 Blade tension
 Bandspannung

Přítlak upnut
 (Tlakový spínač)
 Upper vice is clamped
 (Pressure switch)
 Ober Schraubstock ist gespannt
 (Druckschalter)

04.B.5
 Motory M1, M2, M3 - OK
 Motors M1, M2, M3 - OK
 Motoren M1, M2, M3 - OK






09	Stroj/Machine/Abzähler: Individual 520.360 (D)GH	Název střídky/Name page/Name sellen: Bezpečnostní okruh/Safety circle/Sicherheitsbereich	C:proj./Project/Projekt:	ES-NS30-203/G.1	Lišt:
			Našeťen/Power supply/Energieang:	3x230V/HE, 50Hz	10
			Datum/Date/Datum:	22.1.2013	Lišt0:
			Zpracoval/Processed/Has. verarbeitet:	HALFAR.	.20




BOMAR, s.r.o.,
Teřebnř 1236/1,
CZ 627 00, Brno

**Schemata
Schemata
Schematics**




	BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno	Společnost/Machine: Individual 520.360 (D)GH	Název souboru/Name page/Name sheet: Řídicí systém/Control system/Steuersystem	Číslo projektu/Projekt: ES/NE30203/04.1	List: 11
				Napájení/Power supply/Empeisung: 3x230V+PE, 50Hz	List0: 11
				Datum/Date/Datum: 22.1.2013	List0: 11
				Zpracoval/Processed/Her. ver.arbeitst.: HAL/FAR	List0: 20






ES-NS30-203/G.1	ES-NS30-203/G.1
3x230V/HE, 50Hz	3x230V/HE, 50Hz
22.1.2013	22.1.2013
HALFAR	HALFAR

0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-RCF1	RCF filter	FBOPRL624		91.041.015	1	/04.5			
-RCF2	RCF filter	FBOPRL624		91.041.015	1	/04.a.1			
-RCF3	RCF filter	FBOPRL624		91.041.015	1	/04.a.4			
-RP1	Potentiometer 5k	TP195 4x7/M20A		91.283.015	1	/04.b.5			
=OP1-SB501	Emergency-stop mushroom push-button + 3MVC	YW1B-V4E02R	Bomar	91.060.084	1	/10.2			
-ZD1	Power supply unit - 15VAC/24VDC; 20VAC/28VDC	ZDR-03		265.915	1	/05.2			
-KW1	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/06.1			
-KW2	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.3			
-KW2	Mechanical interlock for contactors DILM12	F-MO DILM12-XMV	EATON	91.041.012	1	/06.3			
-KW3	Contact - 5.5kW, 12A, 3NO+1NC, 24VDC	DILM12-01(24VDC)	EATON	91.040.025	1	/06.4			
-KW3	Auxiliary contact of contactor - 2xNO	F-MO DILA-XH120	EATON	91.041.010	1	/06.4			
-KW11	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.6			
-KW12	Contact - 4kW, 9A, 3NO+1NC, 24VDC	DILEM-01-G(24VDC)	EATON	91.040.024	1	/10.7			
=OP1-HL1	Green light for Eaton adapter	M22-LED-G	EATON	91.061.023	1	/07.a.8			
=OP1-HL2	White light for Eaton adapter	M22-LED-W	EATON	91.061.034	1	/10.8			
=OP1-SB1	Green translucent switch head	M22-DL-G	EATON	91.060.031	1	/09.1			
=OP1-SB1	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.1			
=OP1-SB2	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.2			
=OP1-SB2	Black switch head	M22-D-S	EATON	91.060.035	1	/09.2			
=OP1-SB3	Head of 3 positional switch	M22-WRK3	EATON	91.060.051	1	/09.3			
=OP1-SB3	NO contact for Eaton adapter	M22-K10	EATON	91.061.022	1	/09.3			
=OP1-SB3	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/09.3			
=OP1-SB8	Attaching adapter + NO contact	M22-AK10	EATON	91.061.021	1	/10.4			
=OP1-SB8	Yellow translucent switch head	M22-DL-Y	EATON	91.060.053	1	/10.4			
-FU1	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.8			
-FU2	Tube fuse - 200mA/250V, slow, 5x20	T200mA/250V	ESKA	91.230.037	1	/04.b.9			
-FU3	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.0			
-FU4	Tube fuse - 2A/250V, slow, 5x20	T2A/250V	ESKA	91.230.001	1	/05.1			


0	1	2	3	4	5	6	7	8	9
Parts list									
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page			
-FU5	Tube fuse - 6,3A/250V, slow, 5x20	T6,3A/250V	ESKA	91.230.002	1	/05.4			
-FU6	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/05.4			
-FU7	Tube fuse - 500mA/250V, slow, 5x20	T500mA/250V	ESKA	91.230.011	1	/05.4			
-FU8	Tube fuse - 1A/250V, slow, 5x20	T1A/250V	ESKA	91.230.003	1	/12.1			
-M1	Pump - 120W, 230/400V	4C04-12H	EmP	91.020.015	1	/04.6			
-TR1	Toroidal transformer - 0-230-400V/20V/15V, 0.65-0.36A/6A/2A, 150VA	1502304002015	KARBAN s.r.o.	91.080.026	1	/05.1			
-SQ21	Safety limit switch, 2xNC	QKS8	KEDU	91.173.012	1	/10.2			
-SQ22	Safety limit switch, 2xNC	QKS8	KEDU	91.173.012	1	/10.2			
-PA1	Cylindric fuse - 63A, 14x51 fast, gG characteristic	PV14 63A gG	OEZ	91.230.018	1	/04.b.1			
-PA1	Fused disconnect for cylindric fuse - 3P, size 14	OPV14S-3	OEZ	91.241.003	1	/04.b.1			
-SQ4	Limit switch - 1NC+1NO, M20, slow	D4N-4A31	OMRON	91.173.007	1	/08.4			
-SQ2	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.2			
-SQ3	Limit switch - 1NO + 1NC, roller, M2, snap action	FR 605-M2	PIZZATO	91.173.009	1	/08.3			
-FA1	Motor-overcurrent circuit breaker 0.63-1A	GZ1M05	SCHNEIDER	91.235.023	1	/04.6			
-FA1	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1A111	SCHNEIDER	91.046.004	1	/04.6			
-FA2	Motor-overcurrent circuit breaker 4-6.3A	GZ1M10	SCHNEIDER	91.235.026	1	/04.a.2			
-FA2	Auxiliary contact of MCCB - 1xNO+1xNC	GZ1A111	SCHNEIDER	91.046.004	1	/04.a.2			
-QS1	Main switch 3P, 32A	VCF1-32A	SCHNEIDER	91.170.012	1	/04.0			
-BM1	Safety relay - 4xNO	SNA 4064K	WIELAND	91.051.026	1	/10.4			
-CU1	PRO-4.3	PRO-4.3	Bomar	265.917	1	/11.0			
-FM1	Frequency converter - 4kW, 3x230V	VZA24POBAA	OMRON	91.012.032	1	/04.b.1			
-RET1	Multifunction time relay	CRM-93H/UNI	ELKO	91.051.031	1	/06.7			
-Z1	Filter for frequency converter VZA 24P0	A-1000-FV2030-RE	OMRON	91.012.033	1	/04.b.1			
-FU1	Fuse case	WK4/THSIS...J	WIELAND	91.251.102	1	/04.b.8			
-FU2	Fuse case	WK4/THSIS...J	WIELAND	91.251.102	1	/04.b.9			
-FU3	Fuse case	WK4/THSIS...J	WIELAND	91.251.102	1	/05.0			
-FU4	Fuse case	WK4/THSIS...J	WIELAND	91.251.102	1	/05.1			
-FU5	Fuse case	WK4/THSIS...J	WIELAND	91.251.102	1	/05.4			

0	1	2	3	4	5	6	7	8	9	
Parts list										
Device tag	Device type	Type number	Manufacturer	Part number	Quantity	Page				
-FU6	Fuse case	WK4/THSIS..U	WIELAND	91.251.102	1	/05.4				
-FU7	Fuse case	WK4/THSIS..U	WIELAND	91.251.102	1	/05.4				
-FU8	Fuse case	WK4/THSIS..U	WIELAND	91.251.102	1	/12.1				
-M5	Cooling ventilator - 230V, 50Hz, 0.12A	RAH1278B1-C	XFAN	91.015.105	1	/04.b.8				
13.a 										
BOMAR, s.r.o. Těšební 1236/1 CZ 627 00, Brno		Stroj/Machine/Abstrich: Individual 520.360 (D)GH			Název stávký/Name page/Name sellen: Kusovník artiklů/ Parts list/ Artikelstückliste			C.proj./Project/Projekt: ES: NS30-203/AG.1 Název/Power supply/Einspeisung: 3x230V+PE, 50Hz Datum/Date/Datum: 22.1.2013 Zpracoval/Processed/Has verarbeitet: HALFAR		List: 13.b List: 20

6.4. Hydraulické schéma / Hydraulikschema / Hydraulic diagram



Zdvih stroje / Reise-Tools / Hydraulic saw lift



Základní technické parametry
Technische Spezifikation
Technical specification

Typ / Type / Type	Individual 360 (D)GH (TIN7)
Hydraulický agregát / Hydroaggregat	SSM-3/79+79+16-1/3-17/02400
Hydro aggregat	92.001.062 (19753500)
Neuvedené světlosti / Unerwähnt Lichtbreite	JS6
Unlisted inside diameters	
Výstupní šroubení / Ausgangschraubung	G1/4"
Output screwing	
p_{max}	8 Mpa
Q	21,2+2,2 dm ³ /min
n	1425 ot./min
P	3 kW


205.Y316-000
TIN7
INDIV. 520.360 GH,DGH
15.11.2010

Poz.	Název položky		ks
Pos.	Bezeichnung		Menge
Pos.	Item		Pcs.
1	Nádrž / Behälter / Tank	Ø220-610 mm, 17 l	1
2	Elektromotor / Elektromotor / Electromotor	MA-AL100L 400/230V 50 Hz, 3 kW, 6,68 A	1
3	Hydrogenerátor / Hydraulikgenerator / Hydrogenerator	P23-7,9/7,9/1,6 L62334	1
4	Jednosměrný ventil / Einwegventil / One-way valve	VJ01-06/SG-1	1
5	Přepouštěcí ventil / Bypašventil / By pass valve	VPN1-06/S-10S/M 27999700	1
6	Sací filtr / Filter / Suction filter	2SF56/48-0,063 63 um	3
7	Manometr / Manometer / Manometer	Ø68 0-10 MPa	1
8	Rozváděč / Schaltschrank / Switchboard	SD2E-A3/C2D21 408-0328.003	1
9	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	RJV1-05-0	2
10	Rozváděč / Schaltschrank / Switchboard	RPE3-04Y11/02400E1K1 92.101.005	4(3/2)
11	Rozváděč / Schaltschrank / Switchboard	ROE3-042S2/02400E1K1	1
12	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	VJR1-04/MC 92.103.003	2(1/0)
13	Nalévací zátka / Stopfen / Fill stopper	L1.0406	1
14	---	---	-
15	---	---	-
16	---	---	-
17	Pojistný ventil / Sicherungventil / Safety valve	VPNH ¼ 92.151.001	2
18	Redukční ventil / Reduktionventil /	VRN2-06/S-6R 92.154.001	2(1)
19	Manometr / Manometer / Manometer	Ø68, 0-6 MPa	3(2)
20	Kostka regulace / Regulationklotz / Regulation cube		1
21	Kulový ventil / Kugelventil / Globe valve	99.260.004	1(0)
22	Tlakový spínač / Druckschalter / Pressure switch	0166415031059 20-50 bar	2(1)
23	---	---	-
24	Škrtící ventil / Drosselventil / Throttle-valve	VS01-04/R2,5 92.152.001	2(1)
25	Krycí deska / Schutzplatte / Cover platte	DK 1-04/32-2	2/3(2/3)
26	Hydraulický zámek / Hydraulisches Schloß / Hydraulic lock	VJR1-04/MB 92.103.003	1(0)
27	Rozváděč / Schaltschrank / Switchboard	RPE3-043Z11/02400E1K1 92.101.010	1(0)
28	Jednosměrný ventil / Einwegventil / One-way valve	VJ01-04/MP-30 92.104.001	1(0)
29	Redukční ventil / Reduktionventil /	VRP2-04-PS/6,3 92.154.003	2(0)
30	Clona / Schürze / Shield	0,8 92.153.022	1(0)
31	Rozváděč / Schaltschrank / Switchboard	SD2E-A3/S2D26 408-0328.003	1(0)

7. **Výkresy sestav pro objednání náhradních dílů / Zeichnungen für Bestellung der Ersatzteile / Drawing assemblies for spare parts order**

- Při objednávání náhradních dílů vždy uvádějte: typ stroje (např. practix Individual 520.360 GH) , výrobní číslo (např. 125) a rok výroby (např. 1999).
- In die Bestellung der Ersatzteile führen Sie immer an: Maschinentyp (z. B. Individual 520.360 GH), Serien Nr. (z. B. 125) und Baujahr (z. B. 1999).
- For spare parts order, you must always to allege: type of machine (for example Individual 520.360 GH), serial number (for example 125, see cover page) and year of construction (for example 1999).

7.1. Individual 520.360 GH




NAZEV SESTAVY PILA PASOVA	CÍSLO SESTAVY 201.N300-000	STROJ IN 360GH
Konstruoval:		
Datum: 25. 03.2010		
Meritko: 1:10		

7.2. Kusovník / Stückliste / Piece list – Individual 520.360 GH

Cislo Sestavy 201.N300-000		Ver. 0		Nazev sestavy PILA PASOVA/BAND SAW/BANDSÄGE	
Poz.	Objednací číslo	Ver.	Nazev položky	Rozmer	Ks
1	201.N301-000	0	PODSTAVEC / BASE / UNTERSATZ		1
2	201.N302-100	0	KONZOLA OTOCNA / TURNABLE CONSOL / DREHKONSOLE		1
3	201.N303-100	0	SVERAK / VICE / SCHRAUBSTOCK		1
4	201.Y304-100	2	RAMENO / SHOULDER / SÄGERAHMEN		1
5	201.Y307-010	1	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDER		1
6	201.Y330-000	1	ROZVADEC / DISTRIBUTOR / VERTEILER		1
7	30.N399-001	0	STITEK TYPOVY / MACHINE LABEL / MASCHINE SCHILD	P 0.5x65	1
8	31.0899-004	0	SAMOLEPKA / STICKER / AUFKLEBER		1
9	99.900.039	0	SAMOLEPKA / STICKER / AUFKLEBER	NEBEZP.STLACENI	1
10	99.900.043	0	SAMOLEPKA / STICKER / AUFKLEBER		1
11	99.900.045	0	SAMOLEPKA / STICKER / AUFKLEBER		1
12	99.900.046	0	SAMOLEPKA / STICKER / AUFKLEBER		1
13	99.900.047	0	SAMOLEPKA / STICKER / AUFKLEBER		1
14	99.900.048	0	SAMOLEPKA / STICKER / AUFKLEBER		1
15	99.900.049	0	SAMOLEPKA / STICKER / AUFKLEBER		1
16	99.900.053	0	SAMOLEPKA / STICKER / AUFKLEBER		1
17	99.901.029	0	SAMOLEPKA / STICKER / AUFKLEBER		1
18	99.901.032	0	SAMOLEPKA / STICKER / AUFKLEBER	CETIFIKACNI SAMOLEPKA	1

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Nazev položky/Volume title/Name der Position; Rozmer/Stock size/Abmessung

7.3. Rameno / Sägerahmen / Saw arm 1




MAZEV SESTAVY RAMENO	CÍLOVÝ SESTAVY 201.7304-100	STRUJ. IN360DGH
Konstruoval: MUSIL		Datum: 20. 03. 2012
Meritko: 13:100		

7.4. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 1

Císlo Sestavy 201.Y304-100		Název sestavy RAMENO/SHOULDER/SÄGERAHMEN			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.9114-300	0	KARTAC / BRUSH / BÜRSTE		1
2	201.Y304-010	0	VEDENÍ / GUIDE / BACKENFÜHRUNG	VEDENÍ KRYTÚ	1
3	201.Y305-000	2	POHON / DRIVE / ANTRIEB	POHON PASU	1
4	201.Y308-000	0	MAPINANI / TENSIONING / SPANNUNG		1
5	201.Y310-000	1	VEDENÍ PASU / BELT GUIDE / SÄGEBANDFÜHRUNG		1
6	30.1814-011	1	DRŽAK / HOLDER / HALTER	P 3x76	1
7	30.2904-913	0	PAS PÍLOVÝ / SAW BELT / SÄGEBAND	4780x32(4)x0.90	1
8	30.6014-109	1	PANT / HINGE / TÜRBAND		4
9	30.6014-110	1	PANT / HINGE / TÜRBAND	HR 30x12	4
10	30.7114-142	1	DRŽAK / HOLDER / HALTER	P 4 - 100	1
11	30.T304-014	0	DRŽAK / HOLDER / HALTER	P 4-100	1
12	30.Y304-013	0	DRŽAK / HOLDER / HALTER	P3-30	1
13	30.Y304-018	0	TYC ZAVITOVÁ / THREADED POLE / GEWINDESTANGE	M10	2
14	30.Y304-027	0	KRYT / COVER / ABDECKUNG	P2 - 114	1
15	30.Y304-029	0	KRYT PASU / BELT COVER / BANDABDECKUNG		1
16	30.Y304-030 (1)	0	PLECH / PLATE / BLECH	P 1-15	1
17	30.Y304-031	1	KRYT RAMENE / SHOULDER COVER / RAHMENABDECKUNG		1
18	30.Y304-033	1	DRŽAK / HOLDER / HALTER	L 20x30	1
19	30.Y304-034	1	DRŽAK / HOLDER / HALTER	L 20x30	1
20	30.Y304-035 (2)	0	DESKA / BOARD / PLATTE	HR 20x5	4
21	30.Y304-038	0	ZAMEK / LOCK / SCHLOSS	P4 - 67	2
22	30.Y304-039	0	DRŽAK / HOLDER / HALTER	P3 - 34	2
23	30.Y304-101	6	RAMENO / /		1
24	30.Y304-107	0	DRŽAK / HOLDER / HALTER	P 3 - 40	1
25	30.Y304-109	2	KRYT PASU / BELT COVER / BANDABDECKUNG		1
26	30.Y304-115 (3)	0	KRYT MAPINANI / TENSIONING COVER / BANDSPANNUNGSABDECKUNG	P1,5x244	1
27	30.Y304-132 (4)	0	KRYT RAMENE / SHOULDER COVER / RAHMENABDECKUNG		1
28	31.PK02-054 (1)	0	GUMA / RUBBER / GUMMI	G2 - 206	1
29	90.001.25.009	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5X16	4
30	90.001.25.015	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X10	2
31	90.001.25.034	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	8
32	90.001.25.092	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X14	4
33	90.012.50.007	0	SROUB / ROLLER BOLT / ZYLINDERSCHRAUBE	SROUB M4X30	4
34	90.013.27.003	0	SROUB / BOLT / SCHRAUBE	M5X10	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.5. Rameno / Sägerahmen / Saw arm 2



MAZEV SESTAVY RAMENO	CÍLOVÝ SESTAVY 201.7304-100	STROJ IN360DGH
Konstruoval: MUSIL		Datum: 20. 03. 2012
Merítko: 1:100		


7.6. Kusovník / Stückliste / Piece list – Rameno / Sägerahmen / Saw arm 2

35	90.100.55.006	0	MATICE / NUT / MUTTER	MATICE - M10	6
36	90.150.50.002	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 4,3	4
37	90.150.50.004	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 6,4	4
38	90.151.50.002	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	PODLOZKA 12	2
39	91.070.011	0	VYVODKA / BUSHING / TÜLE	M16x1.5	1
40	91.070.012	0	VYVODKA / BUSHING / TÜLE	M20x1.5	1
41	91.173.010	0	SPINAC KONC.S KLADK. / END SWITCH WITH PULLEY / ENDSCHALTER MIT ROLLE	PZ-FR605-M2	2
42	91.173.012	0	SPINAC KONCOVY / END SWITCH / ENDSCHALTER	OKS8-2xNC	2
43	94.012.001	(2)	RUKOJET / HANDLE / GRIFF		2
44	94.012.002	(2)	ZATKA / PLUG / STOPFEN		4
45	94.202.002	0	REDUKCE / REDUCTION / ADAPTOR / REDUKTION	REDUKCE 6/R1/4"	2
46	99.104.002	0	ZAMEK / LOCK / SCHLOSS	ZAMEK C INSKY	2
47	99.170.001	0	RETEZ ENERGIÍ / ENERGY BELT / ENERGIENETTE	0555.030.075.100	14
48	99.173.001	0	RETEZ ENERGIÍ / ENERGY BELT / ENERGIENETTE	KONCOVKA VNEJ	1
49	99.173.002	0	RETEZ ENERGIÍ / ENERGY BELT / ENERGIENETTE	KONCOVKA VNIT	1
50	99.201.045	(5)	VOZIK LINEARNIHO VEDENI / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA20E SS FO N	1
51	99.201.058	(5)	VOZIK LINEARNIHO VEDENI / LINEAR GUIDE CART / LINEARFÜHRUNGSWAGEN	MSA30E SS FO N	2
52	99.260.003	0	VENTIL / VALVE / VENTIL	1/4"	1

- ZRUS.2xVOZIK HGW 30CC(99.201.007) A NAHR.2xVOZIKEM HSR 30B SS(99.201.027), HGW20 CC(99.201.012)
A NAHR.VOZIKEM HSR 20B SS CI(99.201.025),PRID.GUMA 31.PK02-054,PLECH 30.Y304-030. 120/ZMI49 19.9.2006 SLEZACKOVA
- PRIDANO 4xDESKA 30.Y304-035,2xRUKOJET 94.012.001,4xZATKA 94.012.002. 198/ZM244 11.12.2009 SLEZACKOVA
- ZRUS.2xVOZIK HSR 30B SS(99.201.027) A NAHR.2xVOZIKEM HGW 30CC(99.201.007), HSR 20B SS CI(99.201.025)
A NAHR.VOZIKEM HGW20 CC(99.201.012), KRYT 30.Y304-023 NAHRAZEN KRYTEM 30.Y304-115; 285/zm293 29.10.2010 HLADIL
- KRYT 30.Y304-032 NAHRAZEN KRYTEM 30.Y304-132; 275/zm.302 HLADIL 18.11.2011
- ZRUS,VOZIK LIN.VEDENI 99.201.007 A NAHR.99.201.058,ZRUS.VOZIK LIN.VEDENI 99.201.045 A NAHR.99.201.045 . 056/ZMI100 20.3.2

Cislo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Nazev sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednaci cislo/Purchase order number/Bestellnummer; Nazev polozky/Volume title/Name der Position; Rozmer/Stock size/Abmessung

7.7. Konzola otočná / Drehkonsole / Turnable console




NÁZEV SESTAVY KONZOLA OTOČNÁ	ČÍSLO SESTAVY 201.N302-100	STROJ IN360GH
Konstruoval: MUSIL		Datum: 29. 06. 2010
Meritko: 13:100		

7.8. Kusovník / Stückliste / Piece list –
Konzola otočná / Drehkonsole / Turnable console

Císlo Sestavy 201.N302-100		Ver. 0		Název sestavy KONZOLA OTOČNÁ/TURNABLE CONSOL/DREHKONSOLE	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.Y302-120	0	BRZDA / BRAKE / BREMSE		1
2	201.Y302-150	1	SLOUP / POLE / SÄULE	SESTAVA	1
3	201.Y302-160	3	SLOUP / POLE / SÄULE	SESTAVA	1
4	30.4604-004	0	UKAZATEL / INDICATOR / ZEIGER	P 1,5x15	1
5	30.8602-514	0	PAKA / LEVER / HEBEL		1
6	30.N302-004	0	DESKA / BOARD / PLATTE	P 20 - 430	1
7	30.N302-101	0	KONZOLA / CONSOLE / KONSOLE	SVARENO	1
8	30.Y302-006	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	d 80	1
9	30.Y302-007	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	d 85	1
10	30.Y302-203	1	DESKA / BOARD / PLATTE	P15-150	1
11	30.Y302-204	0	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 30x5	1
12	30.Y302-205	0	ZASLEPKA / PLUG / BLINDFLANSCH	P 1,5x60	1
13	30.Y314-301	0	SKLIZ / SLIDE / RUTSCH	PI-235	1
14	90.001.25.033	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	4
15	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x20	4
16	90.002.2D.017	0	SROUB STAVEČI / ADJUSTMENT BOLT / STELSCHRAUBE	SROUB M12X16	5
17	90.300.0Z.004	0	KOLÍK VALCOVÝ KALENÝ / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLÍK 5X30	2
18	94.002.001	0	RUKOJET / HANDLE / GRIFF		1
19	95.700.004	0	POUZDRO / SLEEVE / BÜCHSE	20x20	1
20	95.720.002	0	POUZDRO / SLEEVE / BÜCHSE	50x50x55	2


Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.9. Sloup / Säule / Pillar - 1




NAZEV SESTAVY SLOUP	CISLO SESTAVY 201.Y302-150	STROJ T360DGH
KONSTRUOVANÍ: MUSIL		Datum: 19. 03. 2012
BOMAR s.r.o.		Meritko: 6:25


7.10. Kusovník / Stückliste / Piece list –
Sloup / Säule / Pillar – 1

NAZEV SESTAVY SLOUP	CÍSLO SESTAVY 201.Y302-150	STROJ T360DGH
		Konstruoval: MUSIL
		Datum: 19. 03. 2012
		Meritko: 6:25



7.11. Sloup / Säule / Pole – 2



NAZEV SESTAVY SLOUP	CÍSLO SESTAVY 201.Y302-160	STROJ IN 360
		Konstruoval: MUSIL
		Datum: 19. 03. 2012
		Meritko: 1:4

7.12. Kusovník / Stückliste / Piece list – Sloup / Säule / Pillar – 2

Císlo Sestavy 201.Y302-160		Název sestavy SLOUP/POLE / SÄULE			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks
1	30.Y302-125 (6)	0	DRZAK / HOLDER / HALTER		1
2	30.Y302-161	5	SLOUP / POLE / SÄULE	SVARENO	1
3	41.001.006 (5)	0	HADICE / HOSE / SCHLAUCH	PG48	2
4	90.001.25.015	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6x10	4
5	90.001.25.033	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	12
6	90.001.25.059	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x35	9
7	90.002.20.028 (2)	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M16x1,5x25	5
8	95.800.021 (5)	0	SEGR HRIDEL. / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 62	2
9	99.200.285 (7)	0	VEDENI LINEARNI / LINEAR GUIDE / LINEARE FUHRUNG	MSA 30R 940 30/30N	1

1. ZRUS.SOUČ. 30.Y302-062 A NAHR. 30.Y502-162,PRID.1xPOJISTNY KROUZEK 95.800.016,
1xHADICE PG36(41.001.005). 075/ZM092 2.4.2009 MUSIL

2.PRIDAN 5xSROUB STAVECI M16x1,5x25 (90.002.2D.028. 093/ZM121 21.5.2009 SLEZACKOVA

3.ZRUS.LINEARNI VEDENI HGR30 L=940 (99.200.108) A NAHR.LIN.VEDENIM HSR30 L=940 (99.200.138).120/ZM149 23.6.2009 SLEZACKOVA

4.ZRUS.LINEARNI VEDENI HGR30 L=940 (99.200.138) A NAHR.LIN.VEDENIM HGR30 L=940 (99.200.108).290/ZM303 5.11.2010 SLEZACKOVA


5.ZRUS.HADICE PG36 (41.001.005) A NAHR.HADICI PG48 (41.001.006),ZRUS.POJISTNY KROUZEK 42 (95.800.016)
A NAHR.POJ.KROUZKEM 62 (95.800.021),ZRUS.UCHYTKA 30.Y502-162 A NAHR.30.Y502-163. 326/ZM014 24.1.2011 SLEZACKOVA

6.ZRUS.DRZAK 30.Y502-163 A NAHR.30.V302-125. 287/ZM322 13.12.2011 SLEZACKOVA

7.ZRUS.LIN.VEDENI 99.200.108 A NAHR.99.200.285 . 056/ZM100 19.3.2012 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednávací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung

7.13. Podstavec / Untersatz / Base





NAZEV SESTAVY PODSTAVEC	ČÍSLO SESTAVY 201.N301-000	STROJ IN360GH
Konstruoval: HLADIL		Datum: 29. 06.2010
Meritko: 13:100		

7.14. Kusovník / Stückliste / Piece list –
Podstavec / Untersatz / Base

Císlo Sestavy 201.N301-000		Ver. 0		Název sestavy PODSTAVEC/BASE/UNTERSATZ	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.D314-130	0	KRYT / COVER / ABDECKUNG	P3-104	1
2	30.N301-002	0	SEGMENT / SEGMENT / SEGMENT	P 12- 197	1
3	30.N301-005	0	EXCENTR / CAM / EXZENTER	d 30	1
4	30.N301-008	0	DRZAK / HOLDER / HALTER	P4 - 212	1
5	30.N301-009	0	DRZAK / HOLDER / HALTER	P 4 - 212	1
6	30.N301-010	0	DRZAK / HOLDER / HALTER	P3 - 234	1
7	30.N301-013	0	KROUZEK / RING / RING	TR 70x12,5	1
8	30.N301-016	0	OKAP / GUTTER CHANNEL / BLECH		1
9	30.N301-041	0	STUPNICE / SCALE / SKALA	P0,5-22	1
10	30.N301-101	0	PODSTAVEC / BASE / UNTERSATZ		1
11	30.N301-103	0	KRYT HYDRAULIKY / HYDRAULIC COVER / HYDRAULIKABDECKUNG		1
12	30.N314-017	0	OKAP / GUTTER CHANNEL / BLECH		1
13	30.Y301-010	0	VANA / TANK / WANNE		1
14	30.Y301-020	0	SKLUZ / SLIDE / RUTSCH		1
15	30.Y401-103	0	CEP / LUG / BOLZEN	d 50 h6	1
16	30.Y502-162	0	UCHYTKA / CLIP / HALTER	P3-80	1
17	41.001.006	0	HADICE / HOSE / SCHLAUCH	55/46	2
18	90.001.25.052	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	1
19	90.002.20.011	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8x10	2
20	91.020.015	0	CERPADLO / PUMP / PUMPE	3COA4-12	1
21	92.001.021	0	AGREGAT HYDRAULICKY / HYDRAULIC GENERATOR / HYDRAULIKAGREGAT	870-1394	1
22	94.101.039	0	ZASLEPKA / PLUG / BLINDEFLANSCH	154x154x4	1
23	95.800.016	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 42	1
24	95.800.021	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 62	1
25	95.800.034	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 55	4

7.15. Svěrák / Schraubstock / Vice



NÁZEV SESTAVY SVERAK	CÍSLO SESTAVY 201.N303-100	STROJ	IN360GH
		Konstruoval: HLADIL Datum: 29. 06.2010 Meritko: 17:100	
			

7.16. Kusovník / Stückliste / Piece list – Svěrák / Schraubstock / Vice


Císlo Sestavy 201.N303-100		Ver. 0		Název sestavy SVERAK/VICE/SCHRAUBSTOCK	
Poz.	Objednáací číslo	Ver.	Název položky	Rozměr	Ks
1	201.Y307-030	0	VALEC SVERAKU / VICE CYLINDER / SCHRAUBSTOCKZYLINDER		1
2	30.2903-012	1	ROST / GRILL / GITTER	P3 - 240	1
3	30.3509-015	1	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	TR 8x1	2
4	30.N303-004	0	CELIST PEVNA / SOLID JAW / FESTE BACKE	P30-195	1
5	30.N303-006	0	BOČNICE / /		1
6	30.N303-009	0	CELIST / JAW / BACKE	HR 200x16	1
7	30.N303-013	0	NOHA / LEG / STÄNDER	P25 - 394	1
8	30.N303-102	0	LISTA VODICI / LEAD TRIM / FÜHRUNGSLEISTE	HR 40x25	2
9	30.N303-110	0	STUL / TABLE / TISCH		1
10	30.N303-112	0	SKLUZ / SLIDE / RUTSCH	PI,5-272	1
11	30.N303-201	1	TELESO SVERAKU / VICE BODY / SCHRAUBSTOCKKÖRPER		1
12	30.N314-002	0	SKLUZ / SLIDE / RUTSCH	PI,5-180	1
13	30.Y303-005	2	CELIST / JAW / BACKE		1
14	30.Y303-104	1	DRŽAK / HOLDER / HALTER		1
15	90.001.25.029	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X12	2
16	90.001.25.032	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	24
17	90.001.25.043	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X12	2
18	90.001.25.048	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X30	4
19	90.001.25.050	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X40	2
20	90.001.25.056	0	SROUB IMBUS ČERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12x20	2
21	90.011.27.010	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M8X10	2
22	90.300.07.035	0	KOLÍK VALCOVÝ KALENÝ / CYLINDRICAL PIN TEMPERED / ZYLINDERSTIFT GEHÄRTET	KOLIK 16X45	2

I.ZRUS.PRILozKA 30.Y309-008,2xSROUB M10x40 (90.001.25.050). 046/ZM255 22.9.2010 SLEZACKOVA

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednáací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung


7.17. Válec svěráku /Schraubstockzylinder / Vice cylinder

Císlo Sestavy 201.Y307-030		Název sestavy VALEC SVĚŘÁKU/VICE CYLINDER/SCHRAUBSTOCKZYLINDER			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1807-005	3	SROUBENÍ / BOLTING / VERSCHRAUBUNG	6-HR 22	2
2	30.2807-109	0	SROUBENÍ PRÍME / DIRECT BOLTING / GERADE VERSCHRAUBUNG		2
3	30.C407-012	1	VÍKO / COVER / DECKEL	d 55	1
4	30.C407-111	0	VÍKO / COVER / DECKEL	d 55	1
5	30.Y307-033	0	VALEC SVĚŘÁKU / VICE CYLINDER / SCHRAUBSTOCKZYLINDER	TR 62/50	1
6	30.Y307-034	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d 28 f8	1
7	30.Y307-035	0	PIST / PISTON / KOLBEN	d 55	1
8	90.001.25.032	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	1
9	95.800.021	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTNY KROUZEK 62	2
10	95.801.009	0	KROUZEK POJIST.VNITR / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNY KROUZEK 52	2
11	96.002.011	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	24X2	1
12	96.002.019	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	46X2	2
13	96.061.009	0	KROUZEK STIRACI / SCRAPER RING / ABSTREIFRING	WD2200280	1
14	96.082.002	0	TESNĚNÍ / SEALING / DICHTUNG	KROUZEK CU 13/17	4
15	96.084.001	0	KROUZEK VODICI / LEAD RING / FÜHRUNGSRING	GP6500500-T47	1
16	96.084.006	0	KROUZEK VODICI / LEAD RING / FÜHRUNGSRING	GR4300280-T47	1
17	96.900.001	0	TESNĚNÍ KOMBINOVA NE / COMBINATION SEALING / KOMBIDICHTUNG		1
18	96.900.021	0	TESNĚNÍ KOMBINOVA NE / COMBINATION SEALING / KOMBIDICHTUNG	RSK200280	1




7.18. Pohon / Antrieb / Drive

Cislo Sestavy 201.Y305-000		Ver. 0		Nazev sestavy POHON/DRIVE / ANTRIEB	
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.1804-010	0	PODLOZKA / WASHER / UNTERLEGSCHIEBE	d 70	1
2	30.2904-002	0	PRIHRUBA / FLANGE / FLANSCH		1
3	30.2904-003	3	KOLO HMACI / DRIVE WHEEL / ANTRIEBSRAD		1
4	30.2904-004	1	HRIDEL / SHAFT / WELLE	d 65	1
5	30.2904-005	0	DISTANC / DISTANCE / DISTANZ	TR 55x8	1
6	30.2904-006	0	PERO / SPRING / FEDER	HR 14x14	1
7	30.2904-008	0	PERO / SPRING / FEDER	HR 12x8	1
8	90.001.25.060	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X40	8
9	90.005.55.045	0	6 HR SROUB ZIN / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M12X50	8
10	90.011.27.009	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHEIBE	SROUB M12X20	1
11	90.150.50.007	0	PODLOZKA DIN125 / WASHER / UNTERLEGSCHIEBE	PODLOZKA I3	16
12	91.001.053	0	ELEKTROMOTOR / ELECTRIC MOTOR / ELEKTROMOTOR	MDEA 100-32pro	1
13	95.001.027	0	LOZISKO / BEARING / LAGER	6309 2RS	2
14	99.002.012	0	PREVODOVKA / TRANSMISSION / GETRIEBE	W110 U P100 B14	1



7.19. Válec zvedací / Hebezyylinder / Lifting cylinder




NAZEV SESTAVY VALEC ZVEDACI	CISLO SESTAVY 201.Y307-010	STROJ 1360
	Konstruoval: MUSIL	
	Datum: 12. 04.2010	
	Meritko: 1:2	

7.20. Kusovník / Stückliste / Piece list –
Válec zvedací / Hebezyylinder / Lifting cylinder

Císlo Sestavy 201.Y307-010		Název sestavy VALEC ZVEDACI/LIFTING CYLINDER/HEBEZYLINDER			
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.0807-008	1	DRZAK / HOLDER / HALTER	HR 40x40	1
2	30.0807-009	1	CEP / LUG / BOLZEN	d 16h9	1
3	30.1807-005	3	SROUBENI / BOLTING / VERSCHRAUBUNG	6-HR 22	1
4	30.8307-205	0	CEP / LUG / BOLZEN	d 16h9	1
5	30.8607-001	0	DRZAK / HOLDER / HALTER	HR 25x25	1
6	30.9107-509	0	SROUBENI / BOLTING / VERSCHRAUBUNG	6HR 22	1
7	30.C407-012	1	VIKO / COVER / DECKEL	d 55	1
8	30.LM07-504	0	PIST / PISTON / KOLBEN	d 55	1
9	30.Y307-002	0	PISTNICE / PISTON ROD / KOLBENSTANGE	d 28 f8	1
10	30.Y307-005	2	VIKO / COVER / DECKEL	d 55	1
11	30.Y307-011	0	VALEC ZVEDACI / LIFTING CYLINDER / HEBEZYLINDER	TR 62/50	1
12	90.001.25.032	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	2
13	90.001.25.034	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X30	1
14	90.101.55.003	0	MATICE / NUT / MUTTER	MATICE M16	1
15	92.002.001	0	SROUBENI PRIME / DIRECT BOLTING / GERADE VERSCHRAUBUNG	GES 08LR	1
16	92.003.001	0	SROUBENI UHLOVE / ANGLE BOLTING / WINKELVERSCHRAUBUNG	P-RSWS-08LR	1
17	92.151.001	0	VENTIL POJISTNY / SAFETY VALVE / SICHERUNGSVENTIL	VPN-H 1/4"	1
18	95.800.007	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 16	2
19	95.801.009	0	KROUZEK POJIST.VNITR / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTNY KROUZEK 52	2
20	96.002.011	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	24X2	1
21	96.002.019	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	46X2	2
22	96.061.009	0	KROUZEK STIRACI / SCRAPER RING / ABSTREIFRING	WD2200280	1
23	96.082.002	0	TESNENI / SEALING / DICHTUNG	KROUZEK CU 13/17	2
24	96.084.001	0	KROUZEK VODICI / LEAD RING / FÜHRUNGSRING	GP6500500-T47	2
25	96.084.006	0	KROUZEK VODICI / LEAD RING / FÜHRUNGSRING	GR4300280-T47	1
26	96.900.001	0	TESNENI KOMBINOVA NE / COMBINATION SEALING / KOMBIDICHTUNG		1
27	96.900.021	0	TESNENI KOMBINOVA NE / COMBINATION SEALING / KOMBIDICHTUNG	RSK200280	1

I.ZRUS.SROUBENI 92.002.005 A NAHR.92.003.001,ZRUS.SROUBENI 30.6107-510 A NAHR.30.9107-509.,ZRUS.I xTESNENI 96.082.002 (ZUSTAVAJI 2ks).071/ZM097 12.4.2010 SLEZACKOVA

7.21. Napínání / Spannung / Tensioning




NAZEV SESTAVY NAPÍNÁNÍ	ČÍSLO SESTAVY 201.Y308-000	STROJ TIN 360
Konstruoval: MUSIL		
Datum: 12. 12.2009		
Meritko: 3:10		

7.22. Kusovník / Stückliste / Piece list – Napínání / Spannung / Tensioning

Císlo Sestavy 201.Y308-000		Název sestavy NAPÍNÁNÍ / TENSIONING / SPANNUNG		Ver. 0	
Poz.	Objednací číslo	Ver.	Název položky	Rozebr	Ks
1	202.2912-100	1	INDIKATOR NAPÍNÁNÍ / POWER INDICATOR / SPANNUNGSINDIKATOR	SESTAVA	1
2	30.0808-001	1	KOSTKA NAPÍNÁNÍ / TENSIONING CUBE / BANDSPANNUNGSWÜRFEL	80x30	1
3	30.0808-002	1	LISTA VODICÍ / LEAD TRIM / FÜHRUNGSLISTE	30x20	2
4	30.0808-006	1	LISTA / TRIM / LEISTE	HR 30x10	2
5	30.0808-007	0	ŠROUB / BOLT / SCHRAUBE	M8x60	1
6	30.1708-004	3	DRŽÁK / HOLDER / HALTER	HR 20x8	1
7	30.2908-001	0	PODLOŽKA / WASHER / UNTERLEGSCHIEBE	ø 50	1
8	30.2908-103	2	KOLO NAPÍNÁNÍ / TENSIONING WHEEL / UMLEHRAD	ODLITEK	1
9	30.4808-101	2	ČEP NAPÍNÁNÍ / TENSIONING LUG / SPANNUNGSBOLZEN		1
10	30.4808-103	1	KROUZEK DISTANČNÍ / DISTANCE RING / DISTANZRING	ø 45	1
11	30.6908-102	1	DRŽÁK / HOLDER / HALTER		1
12	30.7308-001	0	ŠROUB NAPÍNÁNÍ / TENSION BOLT / SCHRAUBE BANDSPANNUNG		1
13	90.001.25.052	0	ŠROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x50	6
14	90.002.20.013	0	STAVEČÍ S KRUŽEL / ADJUSTMENT BOLT / STELLSCHRAUBE	ŠROUB M12x25	1
15	90.011.27.009	0	ŠROUB ZAPUŠTIVÝ / COUNTERSINK BOLT / SENKSCHRAUBE	ŠROUB M12x20	1
16	90.100.35.005	0	MATICE DIN 934 / NUT / MUTTER	MATICE - M8	1
17	90.300.02.003	0	KOLÍK / PIN / BOLZEN	KOLÍK 16x80	1
18	90.350.02.002	0	PRŮŽINA TALÍŘOVÁ / DISC SPRING / TELLERFEDER	35.5X16.3X2.0X2.8	9
19	95.001.028	0	LOŽISKO KULÍKOVÉ / BEARING / LAGER	6307 2RS	2
20	95.800.014	0	KROUZEK POJIST. VNĚJŠÍ / OUTSIDE SAFETY RING / SICHERUNGSRING AUßEN	POJISTIVÝ KROUZEK 35	1
21	95.801.013	0	SEGR DÍRA / INSIDE SAFETY RING / SICHERUNGSRING INNEN	POJISTIVÝ KROUZEK 80	2

7.23. Vedení pásu / Sägebandführung / Belt guide





MZEV SESTAVY VEDENÍ PASU	CÍSOV SESTAVY 201.Y310-000	STROJ IN360DGH
Konstruoval: MUSIL		Datum: 12. 12.2009
Meritko: 33:100		

7.24. Kusovník / Stückliste / Piece list – Vedení pásu / Sägebandführung / Belt guide

Cislo Stavy 201.Y310-000		Mater. sestavy VEDENÍ PASU/BELT GUIDE/SÄGEBANDFÜHRUNG			
Poz.	Objednací číslo	Ver.	Mater. položky	Rozměr	Ks
1	201.2016-000	0	REGULACE PŘÍTLAKU / PRESSURE REGULATION / SCHNITTDRUCKREGULATION		1
2	201.Y310-300	0	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		1
3	201.Y310-400	0	KOSTKA VODICI / LEAD CUBE / FÜHRUNGSKLOTZ		1
4	30.0810-011	0	LISTA TŘECÍ / FRICTION TRIM / FRIKTIONSLEISTE	HR 30x10	1
5	30.2016-006	0	DESKA / BOARD / PLATTE	HR 40x12	1
6	30.3510-004	1	TRUBKA / TUBE / ROHR	TR 8x 1	2
7	30.9010-003	0	DRŽAK / HOLDER / HALTER	PI.5x10	2
8	30.9210-002	1	LISTA VODICI / LEAD TRIM / FÜHRUNGSLEISTE	HR 90x20	1
9	30.Y310-003	0	DRŽAK / HOLDER / HALTER		1
10	30.Y310-007	0	KROUZEK / RING / RING	TR 10x2,5	4
11	30.Y310-008	0	DRŽAK / HOLDER / HALTER	P3-50	1
12	30.Y310-104	0	KONZOLA / CONSOLE / KONSOLE		1
13	30.Y410-006	0	KRYTÍ PASU / BELT COVER / BANDABDECKUNG	P2-70	1
14	30.Y410-008	0	KRYTÍ PASU / BELT COVER / BANDABDECKUNG	P2-70	1
15	90.001.25.016	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X12	8
16	90.001.25.031	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x16	1
17	90.001.25.032	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x20	6
18	90.001.25.033	0	SROUB IMBUS CERNÝ / ALLEN HEAD BOLT / IMBUSSCHRAUBE	8x25	2
19	90.001.25.049	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X35	2
20	90.001.25.061	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M12X45	2
21	90.002.20.022	0	STAVEČÍ S KUŽEL / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M8X30	2
22	90.013.27.003	0	SROUB / BOLT / SCHRAUBE	M5X10	2
23	90.101.55.001	0	MATICE PR.NIŽKA ZN / NUT / MUTTER	MATICE M8	2
24	90.150.50.007	0	PODLOŽKA D11x25 / WASHER / UNTERLEGSCHIBE	PODLOŽKA 13	2
25	90.163.00.001	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	M8 NORD-LOCK	2
26	90.163.00.004	0	PODLOŽKA / WASHER / UNTERLEGSCHIBE	NORD-LOCK	2
27	90.300.02.006	0	KOLÍK / PIN / BOLZEN	KOLÍK 6X32	2
28	90.301.02.013	0	KOLÍK VALCOVÝ MĚKÝ / PIN / BOLZEN	KOLÍK 6X30	2
29	90.302.02.002	0	KUŽEL. KOLÍK S ZÁV. / TAPER PIN / KEGELBOLZEN	KOLÍK 8X30	2
30	94.008.003	0	PAKA UPÍNACÍ / ATTACHMENT LEVER / SPANNHEBEL	M8x40	2
31	94.202.002	0	REDUCEUR / REDUCTION / ADAPTOR / REDUKTION	REDUCEUR 6/RI/4"	2
32	99.280.003	0	VENTIL / VALVE / VENTIL	1/4"	1

7.25. Vodící kostka / Führungsklotz / Guiding cube 1





NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.Y310-300	STROJ IND360
	Konstruoval: HLADIL	
	Datum: 27. 11. 2009	
	Meritko: 7:10	

7.26. Kusovník / Stückliste / Piece list –
Vodící kostka / Führungsklotz / Guiding cube 1

Císlo Sestavy 201.Y310-300		Mazev sestavy KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ			
Poz.	Objednací číslo	Ver.	Mazev položky	Rozměr	Ks
1	30.C210-403		DISTANC / DISTANCE / DISTANZ	TR 16x3	2
2	30.Y310-212		EXCENTR / CAM / EXZENTER	d 15	2
3	30.Y310-301	0	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	1
4	30.Y310-306		SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
5	30.Y310-310	0	DRŽAK TVRDOKOVU / POA HOLDER / HH-HALTER		1
6	30.Y310-320	0	DRŽAK TVRDOKOVU / POA HOLDER / HH-HALTER		1
7	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
8	90.002.20.016	0	SROUB STAVEČI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M12x10	1
9	90.011.27.017	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENMSCHRAUBE	SROUB M6x16	2
10	90.101.55.002	0	MATICE / NUT / MUTTER	MATICE M10	2
11	90.150.50.006		PODLOŽKA DIN125 / WASHER / UNTERLEGSCHIEBE	PODLOŽKA 10,5	4
12	90.301.02.001	0	KOLÍK / PIN / BOLZEN	KOLÍK 10x28	1
13	90.350.02.005	0	PRUŽINA TALIROVA / DISC SPRING / TELLERFEDER	20x10.2x1.1	6
14	95.001.014	0	LOŽISKO / BEARING / LAGER	6200 2RS	5
15	95.800.002	0	KROUZEK POJIST.VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNÝ KROUZEK 8	1

7.27. Vodící kostka / Führungsklotz / Guiding cube 2




NAZEV SESTAVY KOSTKA VODICI	CISLO SESTAVY 201.Y310-400	STROJ 1N360
	Konstruoval: HLADIL	
	Datum: 12. 12. 2009	
	Meritko: 7:10	

7.28. Kusovník / Stückliste / Piece list –
Vodící kostka / Führungsklotz / Guiding cube 2

Císlo Sestavy 201.Y310-400		Ver. 0		Název sestavy KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.1810-102	3	DRZAK / HOLDER / HALTER	TYC 28	1
2	30.C210-403	0	DISTANC / DISTANCE / DISTANZ	TR 16x3	2
3	30.Y310-212	0	EXCENTR / CAM / EXZENTER	d 15	2
4	30.Y310-306	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10x25	1
5	30.Y310-310	0	DRZAK TVRDOKOVU / POA HOLDER / HH-HALTER		1
6	30.Y310-320	0	DRZAK TVRDOKOVU / POA HOLDER / HH-HALTER		1
7	30.Y310-401	2	KOSTKA VODICÍ / LEAD CUBE / FÜHRUNGSKLOTZ	HR 80x50	1
8	90.001.25.010	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M5x20	3
9	90.004.2D.002	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M6x12	1
10	90.005.55.017	0	6 HR SROUB ZIN / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M8x30	1
11	90.011.27.017	0	SROUB ZAPUSTNY / COUNTERSINK BOLT / SENKSCHRAUBE	SROUB M6x16	2
12	90.100.55.005	0	MATICE DIN 934 / NUT / MUTTER	MATICE - M8	1
13	90.101.55.002	0	MATICE PR. NIZKA ZN / NUT / MUTTER	MATICE M10	2
14	90.150.50.006	0	PODLOZKA DIN125 / WASHER / UNTERLEGSCHIEBE	PODLOZKA 10,5	2
15	90.301.0Z.009	0	KOLIK VALCOVY MEKKY / PIN / BOLZEN	KOLIK 10x26	1
16	90.350.0Z.005	0	PRUZINA TALIROVA / DISC SPRING / TELLERFEDER	20x10.2x1.1	6
17	95.001.004	0	LOZISKO KUL I RADE / BEARING / LAGER	6000 2RS	1
18	95.001.014	0	LOZISKO KUL I RADE / BEARING / LAGER	6200 2RS	4
19	95.800.002	0	KROUZEK POJIST. VNEJS / OUTSIDE SAFETY RING / SICHERUNGSRING AUBEN	POJISTNY KROUZEK 8	1

7.29. Rozvaděč / Verteiler / Distributor




7.30. Kusovník / Stückliste / Piece list –
Rozvaděč / Verteiler / Distributor

Císlo Sestavy 201.Y330-000		Ver. 1		Název sestavy ROZVADEČ/DISTRIBUTOR/VERTEILER	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	201.Y330-020	0	PANEL / PANEL		1
2	30.5002-003	0	DRŽAK / HOLDER / HALTER		1
3	30.6030-406	3	PANEL ELEKTRO / ELECTRO PANEL / PANEL	P 3x297x285	1
4	30.6030-413	1	DRŽAK / HOLDER / HALTER	P3x110x140	1
5	30.6130-007	0	ULOŽENÍ / MOUNTING / LAGERUNG	d 30	1
6	30.6130-009	0	PRÍLOŽKA / STRAP / LASCHE	P 3 - 50	1
7	30.6130-010	0	VLOŽKA / INSERT / EINLAGE	d 30	1
8	30.6130-011	0	VEDENÍ / GUIDE / BACKENFÜHRUNG	d 16	1
9	30.6130-012	0	VÍKO / COVER / DECKEL	P 0.5x 30x30	2
10	31.6030-401	0	ELEKTROKRIN / ELECTRIC BOX / ANSCHLUSSKASTEN		1
11	31.6030-414	0	SKLO ORGANICKE / PLEXIGLASS / PLEXIGLAS	3x30x150	1
12	31.6130-008	0	HLAVICE / HEAD / KOPF		1
13	31.Y330-010	0	SAMOLEPKA / STICKER / AUFKLEBER		1
14	90.002.2D.001	0	STAVECI S KUZEL / ADJUSTMENT BOLT / STELLSCHRAUBE	SROUB M4X6	2
15	90.008.50.003	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHEIBE	SROUB M4X10	2
16	90.011.27.001	0	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCHEIBE	SROUB M4X8	2
17	90.100.55.002	0	MATICE / NUT / MUTTER	MATICE - M4	2
18	90.150.50.002	0	PODLOŽKA / WASHER / UNTERLEGSCHLEIBE	PODLOŽKA 4,3	2
19	91.071.022	0	VYVODKA / BUSHING / TÜLLE		2
20	91.072.016	0	MATICE / NUT / MUTTER		2
21	91.283.001	0	POTENCIOMETER / POTENTIOMETER / POTENTIOMETER		1
22		0	/ /		1

1. ZRUS. VYVODKA PG36.91.071.005 A NAHR. VYVODKOU MSV-M50x1.5 91.071.022, PRID. MATICE M50x1.5.
133/ZMI63 17.7.2009 SLEZACKOVA

7.31. Kartáč / Bürste / Brush




NÁZEV SESTAVY KARTÁČ	ČÍSLO SESTAVY 201.9114-300	STROJ EC0260
		Konstrukoval: STASTNA Datum: 18. 11. 2009 Meritko: 7:10


7.32. Kusovník / Stückliste / Piece list –
Kartáč / Bürste / Brush

Císlo Stavby 201.9114-300		Mazec sestavy KARTAC/NAZEV_EN/NAZEV_DE		Ver. 0	
Poz.	Objednací číslo	Ver.	Mazec položky	Rozměr	Ks
1	30.0814-204	0	KOLEČKO / WHEEL / ROLLE	SESTAVA	1
2	30.0814-207	0	KROUZEK / RING / RING	ø 25	2
3	30.9114-301	0	HRDEL / SHAFT / WELLE	ø 12	1
4	30.9214-301	1	DRŽAK / HOLDER / HALTER		1
5	31.0305-211	0	PRUŽINA / SPRING / FEDER	2x12x50x15,5	1
6	31.0814-208	0	KARTAC / BRUSH / BÜRSTE		1
7	31.1506-115	0	PRUŽINA / SPRING / FEDER	1.6x12x25x7.5	2
8	90.001.25.038	0	ŠROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x50	1
9	90.001.25.095	0	ŠROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8x70	2
10	90.003.20.001	0	ŠROUB STAVEČI / ADJUSTMENT BOLT / STELLSCHRAUBE	ŠROUB M5x6	3
11	90.100.55.005	0	MATICE DIN 934 / NUT / MUTTER	MATICE - M8	1
12	90.150.50.005	0	PODLOŽKA DIN125 / WASHER / UMTERLEGSCHLEIBE	PODLOŽKA 8,4	1
13	95.001.005	0	LOŽISKO / BEARING / LAGER	6001 2RS	2

I POZ. 30.9114-301 MAHRAYUJE 30.0814-206 23.1.03 STASTNA

7.33. Regulace přitlaku / Schnittdruckregulation / Pressure into cut regulation



NAZEV SESTAVY REGULACE PRITLAKU	CISLO SESTAVY 001.2016-000	STROJ STG340DGS
	Konstruoval: &konstruoval	
	Datum: 19. 02.2010	
	Meritko: 1:2	


7.34. Kusovník / Stückliste / Piece list –
Regulace přítlaku / Schnittdruckregulation / Pressure into
cut regulation

Císlo Sestavy 201.2016-000		Ver. 0		Název sestavy REGULACE PŘITLAKU/PRESSURE REGULATION/SCHNITTDROCKREGULATION	
Poz.	Objednací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2016-001	2	TELESO / BODY / KÖRPER	HR 40 x 40	1
2	30.2016-002	0	JEHLA / NEEDLE / NADEL	KR 8	1
3	30.2016-003	0	SROUB / BOLT / SCHRAUBE	d 16	1
4	30.2016-004	0	CIDLÓ / SENSOR / SENSOR	d 10	1
5	30.2016-005	0	KOLEČKO / WHEEL / ROLLE	d 32	1
6	30.2016-009	0	KROUZEK / RING / RING	TR 10x1	1
7	31.2016-007	0	PRUŽINA / SPRING / FEDER	d 11.6x11.6	1
8	31.2016-008	0	PRUŽINA / SPRING / FEDER	0.25x3,6x12x9,5	1
9	90.099.002	0	SROUB PULKULATY / HALF ROUND BOLT / HALBRUNDSCHRAUBE	4x6	1
10	90.151.50.003	0	PODLOŽKA / WASHER / UNTERLEGSCHETBE	PODLOŽKA 4	1
11	95.890.001	0	JEHLA / NEEDLE / NADEL	1.5x11.8	1
12	95.891.001	0	KULICKÁ LOŽISKA / BALL / KUGEL	RB 4.5	1
13	96.001.003	0	KROUZEK O STATICKY / STATIC O RING / O-RING STATISCH	8X2	1
14	96.002.001	0	KROUZEK O DYNAMICKY / DYNAMIC O RING / O-RING DYNAMISCH	4X2	2

Císlo Sestavy/Number of assembly/Nummer der Baugruppe; Verze (Ver.)/Version/Version; Název sestavy/Assembly title/Name der Baugruppe; Pozice (Poz.)/Position/Position;
Objednací číslo/Purchase order number/Bestellnummer; Název položky/Volume title/Name der Position; Rozměr/Stock size/Abmessung



7.35. Indikátor napínání / Spannungsindikator / Power indicator

Císlo Sestavy 202.2912-100		Název sestavy INDIKÁTOR NAPÍNÁNÍ / POWER INDICATOR / SPANNUNGSINDIKATOR			
Poz.	Objednávací číslo	Ver.	Název položky	Rozměr	Ks
1	30.2912-101	1	POUZDRO / SLEEVE / BÜCHSE	d 50	1
2	30.2912-102	1	POUZDRO / SLEEVE / BÜCHSE	d 42	1
3	30.T308-052	1	SROUB / BOLT / SCHRAUBE	M3x3	1
4	31.0512-103	0	SAMOLEPKA / STICKER / AUFKLEBER	SÍPKA ZELENÁ	1
5	90.303.0Z.003	0	KOLÍK PRUŽNÝ / PIN / BOLZEN	KOLÍK 4X16	1
6	92.080.005	0	MANOMETR / MANOMETER / MANOMETER	d 63 - 250bar	1
7	95.750.001	0	KROUZEK KU / KU RING / KU-RING	16x1	2
8	96.002.061	0	KROUZEK O DYNAMICKÝ / DYNAMIC O-RING / O-RING DYNAMISCH	ORAR00019-N70	1
9	96.002.062	0	KROUZEK O DYNAMICKÝ / DYNAMIC O-RING / O-RING DYNAMISCH	ORAR00126-N70	1
10	96.082.004	0	KROUZEK CU TESNICÍ / SEAL RING / DICHTUNGSRING	KROUZEK CU 5/9	1
11	96.083.008	0	KROUZEK VODICÍ / LEAD RING / FÜHRUNGSRING	BUI300200-PT00	1
12	96.083.009	0	KROUZEK VODICÍ / LEAD RING / FÜHRUNGSRING	B62000360-PT00	1




7.36. Brzda / Bremse / Brake

Cislo Sestavy 201.Y302-120		Ver. 0		Nazev sestavy BRZDA/BRAKE/BREMSE	
Poz.	Objednaci cislo	Ver.	Nazev polozky	Rozmer	Ks
1	30.Y302-125	0	EXCENTR / CAM / EXZENTER		1
2	30.Y402-022	0	DESKA / BOARD / PLATTE	P2-30	1
3	30.Y402-023	0	SROUB STAVECI / ADJUSTMENT BOLT / STELLSCHRAUBE	6HR 19	2
4	30.Y402-024	0	DESKA / BOARD / PLATTE	HR 80x10	1
5	30.Y402-027	0	KROUZEK / RING / RING	TR 25x5	1
6	30.Y402-028	0	TELESO / BODY / KÖRPER		1
7	30.Y402-029	0	DESKA / BOARD / PLATTE	P 3-15	1
8	90.001.25.015	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X10	2
9	90.001.25.038	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M8X50	2
10	90.001.25.046	0	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M10X20	4
11	90.005.55.015	0	6 HR SROUB ZIN / 6 SIDED BOLT / SECHSKANTSCHRAUBE	SROUB M6X20	1
12	90.101.55.001	0	MATICE PR. NIZKA ZN / NUT / MUTTER	MATICE M8	1
13	95.700.004	0	POUZDRO / SLEEVE / BÜCHSE	20X20	1



7.37. Vedení / Bckenführung / Guide

Cislo Sestavy 201.Y304-010	Ver. 0	Nazev sestavy VEDENÍ / GUIDE / BACKENFÜHRUNG		
Poz.	Objednací číslo	Nazev položky	Rozměr	Ks
1	30.Y304-011	DRŽAK / HOLDER / HALTER	P3 - 100	1
2	90.001.25.016	SROUB IMBUS / ALLEN HEAD BOLT / IMBUSSCHRAUBE	M6X12	2
3	90.011.27.024	SROUB ZAPUSTNÝ / COUNTERSINK BOLT / SENKSCBRAUBE	SROUB M5X20	2
4	90.100.55.003	MATICE DIN 934 / NUT / MUTTER	MATICE - M5	2
5	90.163.00.006	DISTANC / DISTANCE / DISTANZ	TR 10/5.3	2
6	94.101.029	ZATKA / PLUG / STOPFEN	PRO IMBUS M8	6



The diagram shows an exploded view of the guide assembly. It consists of two L-shaped metal brackets (1) that are joined together. The assembly includes two Allen head bolts (2) that pass through the brackets and are secured with nuts (4). Two countersink bolts (3) are used to secure the brackets to a surface. Two distance pieces (5) are placed between the brackets to maintain a specific gap. Finally, six plugs (6) are used to cover the holes in the brackets.

7.38.